

Drone Instructions




READ THIS INSTRUCTIONS FULL BEFORE USE
(PLEASE READ PRECAUTIONS AND WARNINGS SECTION).

Save this manual for future reference.

Suitable for ages 14+

Remote Control




Important safety information

- (1) The product holder must operate and control in a safe way.
- (2) Improper handling may result in serious personal injury or property damage.
- (3) This product is intended for people over 14 years old.
- (4) If you encounter problems with the product during use, please contact the Amazon seller in time.

Safety precautions

- (1) Stay away from obstacles and crowds
The flight speed and state of drone are uncertain. To ensure the safety of people and property around the user, please stay away from crowds, high-rise buildings, high-voltage wires, etc., and avoid flying in bad weather such as wind, rain, and lightning.
- (2) Keep away from humid environment
Drones are composed of many sophisticated electronic components and machinery, so moisture or humidity must be prevented from entering the body to avoid accidents caused by mechanical and electronic component failures.
- (3) Safe operation
Please operate the drone according to the user's own health and operating skills. Fatigue, lack of energy or improper handling can increase the probability of accidental risk.
- (4) Keep away from high-speed rotating parts
When the propeller is flying at high speed, please keep people and objects around the operator away from the rotating parts to avoid danger and damage.

Drone Installation



Battery Charging and Installation Instructions

1. Remote control battery installation

As shown in the picture, put 3 AA batteries (not included) into the battery box of the remote control correctly according to the polarity (+/-).

2. Drone battery charging


- (1) Take out the battery from the box;
- (2) Connect the battery to the USB charging cable, and then plug the charging cable into the power supply;
- (3) The red light is on when the battery is charging, and the light is off when the battery is fully charged.

Charging time is about 60-80 minutes


3. Drone battery installation

Insert a fully charged battery into the drone's battery compartment, then press and hold the power switch until the drone's light turns on.


Operating Instructions for the Remote Control




Flight Control




Headless Mode




Calibration and Reset of the Drone




Frequently Asked Questions




Headless Mode




Calibration and Reset of the Drone




Emergency Stop




360° Flip




One-key Back




Speed Selection




Headless Mode




Calibration and Reset of the Drone




Frequently Asked Questions




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone




Headless Mode




Calibration and Reset of the Drone



Headless Mode



Calibration and Reset of the Drone



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.