

Smart Lock 1.0

Homki-001

User Manual



Leave Your Keys, Enter with Ease



Table Of Contents

Section 1 – Product Highlights

| | | |
|-----|------------------|---|
| 1.1 | Product Features | 1 |
|-----|------------------|---|

Section 2 – Product Overview

| | | |
|------|-------------------------------------|---|
| 2.1 | Product Overview - Outside | 2 |
| 2.2 | Product Overview - Inside | 3 |
| 2.3 | Understanding Your New Lock | 4 |
| 2.4 | ✓ Button | 4 |
| 2.5 | Volume change | 4 |
| 2.6 | Reset Button | 4 |
| 2.7 | Rebooting Your Lock | 5 |
| 2.8 | Low Battery | 5 |
| 2.9 | Changing The Battery | 5 |
| 2.10 | Unlock verification failure alarm | 6 |
| 2.11 | Lock tongue retractable stuck alarm | 6 |
| 2.12 | Anti-lock function | 6 |

Section 3 – Using Your Smart Lock

| | | |
|-----|-------------------------|---|
| 3.1 | Configuring Access | 7 |
| 3.2 | Adding An Access Code | 7 |
| 3.3 | Deleting An Access Code | 7 |

Section 4 – Locking And Unlocking

| | | |
|-----|--|---|
| 4.1 | Locking / Unlocking Using Access Codes | 8 |
| 4.2 | Locking / Unlocking Using App | 8 |
| 4.3 | Locking / Unlocking Using Physical Key | 9 |

Section 5 – Important Notes

| | | |
|-----|-------------------------------|----|
| 5.1 | APP Pairing | 9 |
| 5.2 | Change administrator password | 10 |
| 5.3 | Delete users password | 10 |
| 5.4 | Add users password | 10 |

| | | |
|-----|---------------------------------|----|
| 5.5 | Change users password | 10 |
| 5.6 | Delete users password | 10 |
| 5.7 | Rename password | 11 |
| 5.8 | Change password validity period | 11 |
| 5.9 | View operation history | 11 |

Section 6 – Cleaning

| | | |
|-----|----------|----|
| 6.1 | Cleaning | 11 |
|-----|----------|----|

Section 7 – Safety Precautions

| | | |
|-----|--------------------|----|
| 7.1 | Safety Precautions | 12 |
|-----|--------------------|----|

For Additional Support, Visit [Http://Homki.Afterservice.Vip](http://Homki.Afterservice.Vip)
Or Email Support@Homki.Com
24/7 Support Call: +1(833)6916175



Use Camera or QR
scanner to scan

Product Highlights

1.1 Product Features

Multiple Access Codes & Monitoring

Store up to 150 Access Codes for family, friends and guests, as well as monitor entry and exit records.

Auto-Lock

With Auto Lock enabled, Homki will automatically auto-lock the door based on your customized time setting. You no longer have to worry about forgetting to lock the door.

Backup keys and charging port

The door can be opened with physical backup keys. There is also a type-c connectionsocket for emergency power backup to access the keypad in case your smart lock runs out of Battery.

App control

Your phone is your key, download Tuya mobile app that allows you to lock and unlock doors with a simple icon tap. Homki allow you to add permanent and temporary users, as well as set access schedules for specific days and times. Make sure your smart lock records activity logs so you can go back in time to see who entered or exited your home and when.

Anti-peep keypad


High security, when someone tries to snoop your password, you can enter random numbers before and after the correct password to confuse the judgment. No need to worry about information leakage or changing your password.

One-Touch Locking


When you are in a hurry to go out, long press any key for 2 seconds to manually lock it, reducing unnecessary waiting time.

Product Overview

2.1 Product Overview - Outside



2.2 Product Overview – Inside



2.3 Understanding Your New Lock

After the installation of your new Homki, understanding some key functions of operating your smart lock is important. The following guides will walk you through resetting a lock, adding Access Codes, deleting Access Codes ,and also how to configure your app function. For any questions you can always visit <http://homki.afterservice.vip> for assistance.

Don't forget that Tuya works best with our iOS and Android™ app. Please download the app by visiting the link below.



<https://www.tuya.com/product/app-management/all-in-one-app>

2.4 ✓ button

During the password input process, press the ✓ button once to delete the last entered password number. After deleting all of them, if you are in the add mode, you can exit this mode. After all the entered numbers are deleted, press the ✓ button three times and the screen will turn off.

2.5 Volume change

Press "33 ✓ " on the lock to toggle volume

2.6 Reset Button

Push the reset hole for 5 seconds on the back panel of the Homki-001 to perform your reset. See below to see which Reset Process applies for you. Once the smart lock has been reset, all the data previously stored will be deleted.

2.7 Rebooting Your Lock

To Reboot, find the type-c charging port located on the bottom of the exterior side of Homki-001. Plug in the type c charging cable to charge the device


2.8 Low Battery

When the battery voltage is lower than 4.8V, press the keypad panel, the voice prompts "low battery, please replace the battery", and the backlight flashes rapidly for 1 second. Before the password is unlocked, the voice prompt "low battery, please replace the battery", and then unlock.

2.9 Changing The Battery

Under normal use, the Homki-001 battery will last up to a year. Please check battery levels regularly and change your batteries when the low battery notification is issued. For best practice, always use new batteries by a major brand.

Open the battery compartment cover and insert four (4) new AA alkaline batteries as shown.



2.10 Unlock verification failure alarm

When the wrong single password is entered 5 times in a row, the Bluetooth lock will sound an alarm, and the system will prompt the interface to be locked for 3 minutes.

2.11 Lock tongue retractable stuck alarm


When the lock tongue is stretched and stuck, the Bluetooth lock will try to lock/unlock twice in a row, and if it fails, it will emit a continuous alarm sound.

2.12 Anti-lock function

The electronic anti-lock key of the rear lock, dial the switch, and voice broadcast "the door is locked"; when non-admin users verify the unlocking, the voice broadcast "the door is locked".

To Unlock Anti-lock function:

1. When the administrator verifies that the door is opened, the voice broadcast "anti-lock has been released";
2. Use the APP to open the door and unlock it.



Using Your Smart Lock

3.1 Configuring Access

The Default Access Code is 123456

Your new Homki-001 access code can be any combination of 6 to 8 digits. Once a new access code is entered, the default access code of 123456 would be deleted. A Maximum of 8 sets of access codes can be stored for use.

How to use the keypad

There are a total of ten(10) number buttons on the keypad as shown in the example image to the left.

The button on the bottom is the **One-Touch Locking** button. You will be pressing this button when you are ready to leave home

The ✓ button is the confirm button. You will be pressing this button when you enter your codes.

3.2 Adding an Access Code

Long press ✓ button in the keypad then verify the administrator password and adding User Password

3.3 Deleting an Access Code

Long press the ✓ button in the keypad then verify the administrator, long press the ✓ button again to delete the access code

Locking and Unlocking

Homki-001 can be unlocked using 1 of 3 ways - via your stored access code, smartphone with blue-tooth, or with the physical key supplied with your lock.


4.1 Locking / Unlocking using Access Codes

Enter your 6 to 8 digit Access Code followed by the ✓ button. Press Logo icon anytime to reset if you entered the wrong digit.

If the Access Code entered is correct, the door will unlock. If the Access Code entered is incorrect, Lockly will flash red light


4.2 Locking / Unlocking using App

You must have the Tuya iOS or Android™ app installed in order to lock and unlock with Smartphone. Please download the app by visiting the link below or search “Tuya” from the correct app store.



App unlock/lock: Slide the key icon on the APP to switch the lock/unlock.

4.3 Loking / Unlocking using Physical Key



To unlock your lock using the physical key (included), insert your key and turn clockwise or counter clockwise to lock or unlock the door.

APP Operation Guide

5.1 APP Pairing

After adding an administrator to the lock, press 22 ✓ on the lock, enter the administrator password, Open the Smart Life APP to enter the network configuration mode

5.2 Change administrator password

Enter 11 ✓ on the lock keypad, the original password ▲ new password ▲ new password ▲

Select the lock on the App -> Click "Members" -> Click "Administrator Password" -> Clear the password content -> Enter a new administrator password -> Click "Save".

5.3 Delete users password

In the App, select the lock that needs to be deleted by the phone administrator, click Settings, and then click Delete.

5.4 Add users password

To add custom password [Note: must be operated on the lock edge]

Click "Get Password" on the App -> Select the password type: Custom -> Select the validity period -> Click Set Password -> Enter the password to be added

To add permanent/period/single/cycle password [Note: not require operation on the edge of the lock]

Click "Get Password" on the App -> select the password type: permanent/period/single/clear/cycle -> click to get password

5.5 Change users password

[Note: must be operated on the lock edge]

Select the lock on the app -> click "Members" -> click the password you want to change -> click the password -> enter the new password.

5.6 Delete users password

To clear password [Note: must be operated on the lock edge]

On the App, click "Password Management" -> click the password you want to delete -> click Delete.

5.7 Rename password

Click "Password Management" on the App -> click the password that needs to be renamed -> click the name -> enter the new name.

5.8 Change password validity period

[Note: must be operated on the lock edge]

Click "Password Management" on the App -> click the password whose validity period needs to be changed -> click the validity period -> enter a new validity period -> click Save.

5.9 View operation history

Select the door lock on the App, and click the operation record to view it.

Note: When there is no wifi gateway, the unlock record of the password can only be viewed after unlocking through the App.

Click a password on the App, click the operation record, and view all records of this password.

Cleaning

6.1 Cleaning

Making sure your Homki-001 is clean is best practice to ensure optimal product use. Follow the DOs and DON'Ts below.

| DO | DON'T |
|--|---|
| <ul style="list-style-type: none"> · Rinse the touchscreen with warm water prior to cleaning. · Use the application of soap with a damp, lukewarm cloth. · Air dry or wipe dry with a soft microfiber cloth to avoid scratches. | <ul style="list-style-type: none"> · Don't use abrasives, high alkaline cleaners, or gasoline to clean your lock. · Don't apply cleaning detergent directly in sunlight or at high temperatures. · Don't leave cleaning detergent on the display keypad for long periods of time - wash immediately. · Don't use scrapers, squeegees or razors. |

Safety Precautions

7.1 Safety Precautions

Please read all instructions carefully. Remind all Homki-001 users of the safety precautions.

- Do not attempt to disassemble the smart lock by yourself. It can cause product damage, void warranty, and cause injuries.
- Do not use any inappropriate tools that can cause damages or malfunction to your lock.
- Always make sure your door is securely closed and locked when you leave your house to prevent unwanted entry.
- Always dispose of used batteries according to your local laws. DO NOT BURN.

FCC Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause.

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2:

Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. FCC Radiation Exposure Statement

The Secure Link Wi-Fi Hub complies with FCC radiation exposure limits set forth for an uncontrolled environment. It should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC ID:2A8TGHOMKI-01