





Size: 45*45mm

Mini BLE Gateway User Manual Model: BT03	Presentation Red indicator (network configuration) Blue indicator (subdevice) Charging port Reset button -2-	Specification Size: 50*50*11mm Input: DC 5V/1A Bluetooth: Low-power 4.2 Working temperature: 0 C~50 C Working humidity: 10%~85% RH Storage temperature: 0 C~70 C Storage humidity: 5%~95% RH -3-	Checklist before usage: a. Your smartphone has connected to a 2.4GHz Wi-Fi network. b. Input the correct Wi-Fi password. c. Your smartphone must be Android 4.4 + or iOS 8.0 +. d. If numbers of devices connected to the Wi-Fi router reach the limit, you can try to disable device to vacate channel or try another Wi-Fi router. -4-	How to set up: 1. Use your smartphone to scan below QR code, or search "Smart Life" app in Google Play Store or APP Store to download and install.   QR Code 2. Create an account with your mobile number and authentication code. -5-	 3. Connect your mobile to your Wi-Fi router, click "+" in the upper right corner of homepage or click "Add Device".  -6-	 4. Supply power to the gateway with supplied charging cable. 1) Bluetooth Mode Please turn on the bluetooth on your mobile, the app will search the nearby device, enter wifi name and password, it will connect to App automatically. -7-	  -8-
---	---	---	--	--	---	--	--

2) Wi-Fi Mode Select "Wireless Gateway (BLE)" from "Gateway Control", then select "Wi-Fi Mode", make sure the blue indicator is on and red indicator is blinking slowly. Enter wifi name and password, connect your mobile to device's hotspot: "SmartLife-XXXX", then click to return to App interface, it will connect. -9-	 -10-	 -11-	 5. Click "+ Add device", make sure the LED indicator of the subdevice is blinking, App will search the device automatically. After device is added, you can monitor or control it remotely.  -12-	FCC Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. To assure continued compliance, any changes or modifications not expressly approved by the party. Responsible for compliance could void the user's authority to operate this equipment. (Example-use only shielded interface cables when connecting to computer or peripheral devices). This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. FCC Radiation Exposure Statement: The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. -13-	
--	---	--	--	--	--