


Keys' Functions



Specifications


IMU	6-axis IMU sensors
BT	Bluetooth 5.1 LE
Power supply mode	2 x AAA Batteries
Standby duration	6 months * 2 x AAA Batteries, entering deep sleep mode
Upgrade	OTA
Signal feedback	Linear motor (Vibration latency<0.1s)
Tracking Distance	10cm~100cm
Position accuracy	< 3%
Position precision	< 0.5mm
Rotation accuracy	< 1.5°
Rotation precision	< 0.05°

Indicator Status

Status	Normal Power	Low Battery
Power off	LED All off	LED All off
Adv state (Paired)	Red LED off Blue LED 1Hz slow flash	Red LED 2Hz slow flash Blue LED 1Hz flash Alternating red and blue
Adv state (Unpaired)	Red LED off Blue LED 10Hz flash	Red LED 2Hz slow flash Blue LED 10Hz flash Alternating red and blue
Connected state	Blue LED on	Blue LED on, Red LED 2Hz slow flash
OTA state	Red LED and Green LED 1Hz slow flash (Yellow)	Red LED and Green LED 1Hz slow flash (Yellow)

\*To connect and pair your controller : Press [Power]+[Trigger] at the same time

Product Label



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note 2: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.