

DMX BOX

DMX BOX display interface and the relationship between transmitting:

1. DMX BOX on the electric light "CHN" indicator light shows the default number "1", press "+" and "-" buttons can change the number 1 to 7. All operations are automatically remembered and automatically restored after being powered on.



2. Relations with transmitting digital display

Numbers "1" -- launched 2430 MHZ carrier

Number "2" - only launch 2445 MHZ carrier

Number "3" - only launch 2455 MHZ only carrier

Number "4" -- launched 2430 MHZ on load

Number "5" - launch 2445 MHZ on load

Number "6" - launch 2455 MHZ on load

Number "7" - 2430 MHZ - 2445 MHZ to 2455 MHZ three frequency cycle for frequent load signal

The transmission power of DMX BOX has been set to the maximum by default. If you need to adjust it, you can perform the following operations:

Long press "SET" button for 2 seconds, the "RANGE" light flashing, can use the "+", "-" button 1-12 power. First gear power minimum power, 12 gear power maximum. After selecting the power gear, you need to press ENTER. If you do not press save, the machine will automatically exit the power setting and restore the previous power value after 30 seconds.



Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.