




## USER MANUAL

Fit for Model No. E527 series.




### 1 Main parameters

Material: plastic and electronic components  
Batteries: Car battery: 4.8V AA rechargeable battery;  
Remote controller battery: 2 pcs of 1.5V AA batteries.



### 2 Battery Installation

1. Open the cover of battery case locates in the back of controller, inserts 2 pcs of 1.5V AA batteries into the battery case, and then screw the cover (Fig 2A).
2. Please screw out the cover at the back of car by screwdriver, open the cover as the arrow showed, insert 1pcs of 4.8 V AA battery, then screw the cover (Fig 2B).




Notice: Battery needs to be charged for the first time use.  
Images are for reference only and may differ from the real product, specific please prevail in kind.

### 3 Installing the sprinkler head and filling the water tank

1. Open the colorful box, unpack the blister packing in the upper left corner of the remote control car, take the car out, rotate the fountain, and install the sprinkler head. (Fig 3A)

2. To operate the function of spraying, open the water tank and fill it with clean water (in order to avoid damaging the car, the water tank should be empty, when the remote control car is not used or the function of spraying is not performed for a long period). (Fig 3B)



### 4 2.4G Auto Coding

1. After installing the batteries on the car and the remote controller, turn on the power of both. There is a sound of DI from the car, and the indicator on the remote controller and the lights on the car would be flashing slowly. That means the car is in a state of coding, the auto-coding would be successful if the car with DI-DI sound.
2. Each remote controller could be only coded with one car. There is no any interference if auto-coding is success.
3. It could be re-auto-coded with other car or remote controller by turning off the power of both.

