


FLYING ACE REMOTE CONTROL



Instruction Manual

Flying Ace: Requires 3 x "AAA" (LRO3) batteries (not included) Controller: Requires 2 x "AAA" (LRO3) batteries (included)

© Peanuts Worldwide LLC www.peanuts.com © 2015 Twentieth Century Fox Film Corporation



Just Play logo ©2015 Just Play, LLC. 4850 T-Rex Ave, Suite 100 Boca Raton, FL 33431, USA

In the interest of better quality and value, we are constantly improving and updating our products. Consequently, pictures on this package may sometimes vary from the product enclosed.

Please retain this address for future reference.

CAUTION: Have an adult remove and dispose of all packaging, ties and fasteners before use

PRINTED IN CHINA

Item # 45050

Follow Just Play on:

justplayproducts.com

https://facebook.com/JustPlay

https://twitter.com/JustPlayToys http://instagram.com/justplayproducts


https://pinterest.com/JustPlayToys

CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.




Battery Safety Information:

Flying Ace: Requires 3 x "AAA" (LRO3) batteries (not included)



Requires 2 x "AAA" (LRO3) batteries (included)



Battery Instructions

- 1. Remove batteries when not in use or discharged.
- Do not mix old and new batteries.
- Do not use rechargeable batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

Product is shipped in "Try Me" mode for demonstration purposes. Please switch from "Try Me" to "On" for normal play mode.

Replacement of batteries must be done by adult.

Dispose of batteries safely.

Never dispose of batteries in fire, as they may leak and explode.

ATTENTION: The batteries included in this unit are only intended for in-store demonstration. It is possible that they may become weak or discharged prior to purchase and customer may find it necessary to replace the included batteries with fresh cells to ensure proper operation.

CAUTION: Changes or modification not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :


Reorient or relocate the receiving antenna.


Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions :

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired





How to Play:

a. Controller- 3 mode switches on the back: On, Try Me, Off b. Flying Ace - 2 mode switches on the bottom: On & Off

Try Me Mode:

Switch from Try Me to On Mode.

Turn the switch to "On" mode from the back of the controller.

Turn the switch to "On" mode on the bottom of the Flying Ace.

Press the "Forward" button on the controller and Flying Ace will move forward and you will hear sound effects. Release the button and then it will stop moving.

Press the "Spin" button on the controller and Flying Ace will turn back clockwise and you will hear sounds. Release the button and the Flying Ace will stop moving.

Press both buttons and Flying Ace will move forward and you will hear sound effects.

**Sleep Mode - The Controllers "On" mode will not respond if there is no play for 30 seconds to protect the batteries from running out. If the Controller goes to "Sleep" mode, please turn it to Off then back to start it again. Please turn the Flying Ace to Off Mode when not in use.

Remote Distance - 10 Feet (3 Meter)

FCC ID: 2AAIB4505000