

Technical Specifications

Emitter

Asian frequency: 88.3MHz

Modulation mode: FM

Emission distance: 3 m (with no interference)

Reception from any audio and visual equipment with audio out socket, such as TV set, audio device, DVD/VCD player, multimedia PC, MP3, walkman, etc.

Power supply: 2 × AAA batteries or 4.5V DC

Receiver

Frequency range: 84–108MHz

Reception Mode: FM

Distortion: ≤2%

Power Supply: 2 × AAA batteries

Notes

- To achieve best reception spread out emitter audio cable of the emitter (the emitter audio cable can also be used as antenna).
- If the sound is distorted or too strong, adjust the volume of the signal source (TV set, VCD player, DVD player, PC, MP3, walkman etc.) to a lower level, and reception performance may be improve.
- Replace the batteries if you are having the following problems.
 1. The emitter indicator becomes dim.
 2. The receiver reception is poor.
 3. The volume becomes weak and the sound is distorted.

FCC Notice: this device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Parts

Package includes:	
Emitter	1
Receiver (Headphone)	1
Instruction Manual	1
The following parts are optional (to be purchased additionally)	
Audio cable	1
Y adaptor cable	1
Power adaptor	1

Installation

Installing the receiver:

Insert two AAA batteries into the battery compartment according to the + and - polarity.

Installing the emitter:

Insert two AAA batteries into the battery compartment according to the + and - polarity, or insert the power adaptor (optional) into power socket of emitter (4.5V DC).

Insert audio plug of the emitter into AUDIO-OUT socket of audio source (such as TV set, audio device, PC, DVD player, CD player, MP3 player, etc.). In case the audio out socket of the audio source is the headphone socket, The Y adaptor cable can be used for connection (see Fig.1). To achieve best reception spread out emitter audio cable which can be also used as antenna.

Operation





Wireless headphone

1. Insert the emitter audio cable into the AUDIO-OUT socket of the electrical device (see Fig.1) or earphone socket, and move the function switch of the emitter to the

Appearance and Function Illustrations

A Receiver

1. Battery compartment cover
2. Volume control and power button (ON/OFF)
3. Scan key (SCAN)
4. Reset key (RESET)
5. Power indicator
6. Audio socket



B Emitter

7. Power indicator (front)
8. Power and function switch
9. Microphone socket (MIC)
10. Power socket (4.5V DC)
11. Microphone (MIC)
12. Audio cable of emitter
13. Battery compartment cover (bottom)