

**NUVELON™**  **Bluetooth®**

**ILLUMINATED  
DANCING  
WATER SPEAKERS**



*Your music  
creates  
a multicolor  
water and  
light show*


# USER MANUAL

MODEL WHI-096

## Congratulations on your purchase!

Thank you for purchasing NUVELON'S Illuminated Dancing Water Speakers.

Now it's time to experience your music in a whole new way!



**2 SPEAKERS**  
(Main and Auxiliary Speakers)

### WHAT'S IN THE BOX



**USB POWER  
CHARGING  
CORD**



**SPEAKER  
CONNECTING  
CORD**




**USER MANUAL**

### OPERATING INSTRUCTIONS

#### 1. FULLY CHARGE THE MAIN SPEAKER


Charge the main speaker by plugging the USB end of the charging cord into your laptop, USB charger, USB battery, or other power source that has a USB jack (not included). Plug the other end of the charging cord into the port labeled 'USB POWER' on the back of the main speaker.



Approximately 8 hours is required for a full charge. NUVELON speakers can play while charging. CHARGING STATUS IS INDICATED BY A RED LIGHT ON THE BACK OF THE SPEAKER. When charging, this light will be illuminated. When fully charged, the red light will turn off.

#### 2. CONNECT THE SPEAKERS

Connect the main speaker to the auxiliary speaker by plugging the ends of the speaker connecting cord into the back of each speaker. This cord plugs into the ports labeled 'SPEAKER'.



#### 3. POWER UP

Slide the ON / OFF switch located on the back of the main speaker to the 'ON' position. If power is supplied to the speakers, or if the batteries are fully charged, you will hear a single-tone chime after a couple of seconds, the speaker lights will illuminate, and the water jets will briefly turn on. When speakers are not in use, turn them off by sliding switch on main speaker to "OFF" position.

#### 4. PAIRING WITH YOUR BLUETOOTH® ENABLED DEVICE\*

- On your device, make sure Bluetooth® connectivity is turned on. Choose Settings > General > Bluetooth®, and slide or switch to ON. (if you can't find your device's Bluetooth® connectivity menu, refer to your device's instruction manual)
- When Bluetooth® connectivity is turned on, your device will display a list of discoverable Bluetooth® devices. Choose 'NUVELON' from this list, and after a few moments you will hear the speakers respond to the connection request with short chimes.
- Now you're ready to play. Choose music from your device's playlist, and control volume through the volume control on your device. IF THE WATER JETS DO NOT FUNCTION AT FIRST, TURN THE VOLUME UP. When paired, all audio signals from your device, including incoming calls and alerts, will be routed to the speakers.
- To unpair a device, go to your device's Bluetooth® menu, select 'NUVELON', and choose 'Forget this Device'. (refer to your device's instruction manual if necessary).

Nuvelon speakers have a connectivity range of approximately 30ft. (10m). If your device moves out of this range while streaming music to the speakers, Bluetooth® connectivity will be lost and music will revert to playing on your device. To reestablish connectivity, move back in range. If your music does not play or you do not hear a reconnection chime after moving in range, reselect music or reconnect in your device's Bluetooth® menu. Reconnecting will be necessary if another device has established connectivity while you were out of range.

\*NUVELON SPEAKERS CONNECT WITH MOST BLUETOOTH ENABLED DEVICES LIKE SMARTPHONES, TABLETS, LAPTOPS AND MP3 PLAYERS. IF YOU ARE HAVING DIFFICULTY PAIRING WITH YOUR BLUETOOTH® ENABLED DEVICE, PLEASE CONSULT THE TROUBLESHOOTING CHART OVERLEAF.

## TROUBLESHOOTING TIPS

### Bluetooth® enabled device will not connect with the speakers

- The Bluetooth® enabled device is not recognizing the NUVELON speakers. Consult the device's instruction manual.
- The device is too far away. The maximum distance of the device from the speakers should not exceed approximately 30 feet (10m).
- Path between device and speakers is obstructed. Sound interference can be caused by obstacles such as walls and other objects.
- The Bluetooth® device and the speakers may not have been properly paired. Please refer to the Operating Instructions section of the reverse side of this manual and retry the pairing steps.

### Speakers are paired, but there is no sound

- There is no power. Check the speakers are correctly plugged into a power source, or that the batteries are charged.
- The volume is too low. Adjust the output volume on your device.
- The output device may have lost wireless connection to your origin audio source (eg. Internet radio). Check that your device is receiving a signal from the origin source.

*If you are still having difficulty pairing your speakers with your Bluetooth® enabled device after reading these troubleshooting tips, please contact a Customer Service Representative by calling us toll-free on (1) 866-652-8064, or email [customerservice@forevergiftsinc.com](mailto:customerservice@forevergiftsinc.com) so we can assist you.*

**IMPORTANT SAFEGUARDS:** When using an electrical product, basic precautions should always be followed, including the following:

#### **READ ALL INSTRUCTIONS BEFORE USING**

**WARNING:** Do not place speakers too close to ears. Excessive volume may cause damage to ear drums, especially in young children.

- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by Nuvelon.
- Nuvelon is not liable for any damage caused to smartphones, iPod/MP3 player, or any other device.
- Do not place or store this product where it can fall or be dropped into a tub or sink.
- Do not place or drop into water or any other liquid.
- Not for use by children. THIS PRODUCT IS NOT A TOY.
- Never operate this product if it has a damaged cord, plug, cable or housing.
- Keep away from heated surfaces.
- Use only on dry, level surfaces. Do not place on any surface wet from liquids or cleaners.

*Keep this instruction manual for future reference. Comply with all warnings and notes provided. Adverse conditions such as cold, extreme cold, extreme heat, humidity and dampness may affect speaker performance. When audio is transferred by Bluetooth® technology, performance and sound quality are dependent on distance of Bluetooth® enabled device from speakers.*

**WARNING:** Do not expose speakers to excessive heat such as sunshine, fire, or other high temperatures.

**CAUTION:** Never attempt to open or disassemble speakers as injury may occur. Electronics must be recycled or disposed of properly. Always connect using the correct power supply. Keep packaging and parts out of the reach of children. Films and other packaging materials may pose a suffocation risk.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna - Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**WARNING:** Changes or modifications to the equipment that are not expressly approved by the responsible party for compliance could void the user's authority to operate the equipment.

#### **NUVELON One Year Limited Warranty**

For detailed Warranty instructions and information visit:

<http://www.forevergiftsinc.com/warranty/Nuvelon-dancing-water-speakers.html>

*To obtain warranty service on your NUVELON product, contact a Customer Service Representative by calling (1) 866-652-8064 between 8:30am - 5:00pm CST Monday to Friday, or send an email to [customerservice@forevergiftsinc.com](mailto:customerservice@forevergiftsinc.com).*

*Please have the product model number available (see over).*