



# KR06B Remote control

-User manual for KR06B-5  
KR06B-2  
KR06B-1



## Feature

Simple and flat design of button;  
Independent button design for dot moving;  
intermediate stop position;  
Programming of coding and limit by remote control.

## Specifications:

Frequency: ASK433.92MHZ  
Emitting Power: <10mW  
Battery: 2\*AAA 1.5V

## Functions and Setting

### Coding(Receiver is provided)

- 1、When the receiver enters the coding mode, press the [button Coding] within 15 seconds, and the LED in receiver flashes 3 times to tell it is done.
- 2、Within 3 seconds once the receiver is powered on, press the [button F1], the receiver's LED get on, and then within 15 seconds, press the button Coding, and the LED in receiver flashes 3 times to tell it is done.

Read carefully before use and keep for future reference

### Reverse turning(Receiver is provided)

- 1、When the receiver enters the coding mode, press the [button Down] within 15 seconds, and the LED in receiver flashes 3 times to tell it is done.
- 2、Keep pressing the [button SET] and [button DOWN] simultaneously for 3 seconds the LED in the receiver flashes 3 times to tell it is done.

### Clearing(Receiver is provided)

Keep pressing the [button SET] and [button UP] simultaneously for 3 seconds the LED in the receiver flashes 3 times. Then within 15 seconds, keep pressing the [button SET] and [button UP] simultaneously for 3 seconds again, the LED in the receiver flashes 3 times to tell it is done.

### Limit Setting(Receiver is provided)

Keep pressing the button F1 and button Stop simultaneously for 3 seconds the LED in the receiver flashes 3 times, then the system enters limit setting mode, please adjust the limit for both ends and confirm each limit by pressing [button F1], then the LED in the receiver flashes for 3 time to tell it is done.

### Intermediate stop position(Receiver is provided)

Press the button Intermediate stop position, the motor automatically moves to the preset intermediate stop limit position.

### Wireless operating

[Button UP], makes the system working and open the curtain.  
[Button Down], makes the system working and close the curtain.  
[Button Stop], stop moving.  
[Button Upward] dot moving, the motor moves as dot moving mode.  
[Button Downward] dot moving, the motor moves as dot moving mode.  
[Button Intermediate Stop position], the motor travels to the preset intermediate stop limit position.

### Channel change(Not available in single channel type)

The left button for change, it goes to the previous channel.  
The right button for change, it goes to the next channel.  
The LEDs are all on in one channel.

The remote is used to control the Motor of automatic curtain (Check the below pic.)



## **FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## **RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.