

Instruction Manual

BATTERY INSTALLATION

The base unit operates on 2 AAA batteries and the remote sensor operates on 2 AAA batteries (batteries not included). Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.

(Tip: Lithium batteries are recommended in extremely cold or hot locations.)

IMPORTANT: Install batteries in the base unit first, then the remote sensor, otherwise the units' transmissions may not properly connect. Place the base unit as close as possible to the remote sensor when installing batteries.

Base Unit

The battery compartment is located on the back of the unit. Remove the battery compartment door. Install (2) AAA size batteries into the battery compartment according to the polarity markings. Replace the battery compartment door.

Remote Sensor

The battery compartment is located under the table stand on the back of the unit. Pull up the table stand to access the battery compartment. Remove the 4 screws from the battery compartment cover (take care not to misplace the screws). Install (2) AAA size batteries into the battery compartment according to the polarity markings. Replace the battery compartment door and the screws.

After Batteries are Installed:

Allow 3 minutes for the base unit to read current temperature conditions and connect with the remote sensor. A transmission signal icon (“”) flashes on the base unit during this time. After 3 minutes, the transmission signal will flash when a signal is received from the remote sensor.

The remote transmits temperatures once a minute. The red LED indicator light on the remote flashes when a signal is sent.

Note: The outdoor temperature display on the base unit will display dashes (“--”) until the 1st remote sensor signal is sent.

TEMPERATURE READINGS

The base unit displays the indoor temperature (“IN”) from its location.

The remote unit transmits outdoor temperature (“OUT”) from its location back to the base unit.

Press the “°C/°F” button on the base unit to switch between Fahrenheit or Celsius temperature displays.

MAXIMUM/MINIMUM TEMPERATURE READINGS

- Press the “MAX/MIN” button once to display the maximum indoor and outdoor temperature readings since the unit was last reset. “MAX” will show on the LCD.
- Press the “MAX/MIN” button a second time to display the minimum indoor and outdoor temperature readings since the unit was last reset. “MIN” will show on the LCD.
- Press the “MAX/MIN” button a third time to see current indoor and outdoor temperatures.

To clear the maximum and minimum readings: In either MAX or MIN mode, press and hold the “MAX/MIN” button for 2 seconds to clear both memories. The temperature displays show dashes “--” and the unit will begin to track new MAX and MIN readings. The memories will also reset when the base units’ batteries are removed.

CLOCK SETTING

The Clock display is located to the right of the Indoor Temperature display.

1. Press and hold the “SET” button for 2 seconds to enter Clock Setting Mode. The hour digit blinks.
2. Press the “+” button to change the hours. Press “SET” to confirm. The minute digits blink.
3. Press the “+” button to change the minutes. Press “SET” to confirm. “12” or “24” blinks in place of the minute digits.

4. Press “+” to toggle between 12 or 24 hour clock mode. Press “SET” to confirm. The hour and minute digits reappear. The clock is set.

Notes: If no buttons are pressed within 30 seconds, the unit will automatically exit Clock Setting mode. Until a time has been set, the clock will count up the time since battery installation.

DISPLAYING YOUR WEATHERGUIDE

Base unit

Pull the bottom of the Table Stand located on the back of the base unit to set it on a flat surface. Place the base unit indoors in a well-ventilated location away from direct sunlight.

Remote sensor

Pull the bottom of the Table Stand located on the back of the remote sensor to set it on a flat surface, or use the recessed keyhole on the back of the remote to hang on a wall using a nail or screw (not included).

The transmission range of the remote sensor is 100 feet. The effective transmission range is vastly affected by obstacles such as walls, sheds, trees, etc. Try various set ups for the best results. Shorten the distance between the base and remote units when necessary.

To get the most accurate readings and to prolong the life of your sensor, we recommend that you mount it out of direct sunlight and rain. Direct sunlight will heat the casing and inflate temperatures readings. Place the sensor in a dry, shaded area. Fog and mist will not affect the sensor, but large volumes of soaking rain may. To guard against this, we recommend that you mount it under the eave of your house, your garage or any other suitable place that will keep it out of direct sun and rain.

Important: Though the remote unit is weather proof, it should be placed away from direct sunlight, rain, snow and should never be submerged in water.

LOW BATTERY

Remote sensor: replace the batteries when “” appears on the base unit.

Base unit: replace the batteries if readings grow dim or irregular.

Always replace all batteries in each unit at the same time; do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.

NOTE: Please recycle or dispose of batteries per local regulations.

WARNING: Batteries may pose a choking hazard. As with all small items, do not let children handle batteries. If swallowed, seek medical attention immediately.

PRECAUTION: Do not dispose of batteries in fire. Batteries may explode or leak. Remove the batteries if the units will not be used for a long period of time.

PROBLEM SOLVING

1. If the base unit does not receive a transmission from the remote sensor, the outdoor temperature display will show dashes. To correct this problem:

a) Check that the remote is properly positioned, within the appropriate transmission range (100 feet).

Transmissions are vastly affected by building materials and where the receiver and remote units are positioned.

Try various set ups for the best results. Shorten the distance between receiver and remote units when necessary.

b) Check to make sure the transmission path is clear of obstacles and interference.

c) Place the remote sensor closer to the base unit.

d) Remove and reinstall all batteries. Try fresh batteries.

2. If the temperature is higher than the range of the unit, the display will show “HH.H”. If the temperature is lower, this display will show “LL.L”.

- Indoor temperature range is 32°F to 122°F (0°C to 50°C)

- Outdoor temperature range is -40°F to 158°F (-40°C to 70°C)

3. The temperature sensors are manufactured to the accurate within plus or minus one degree, so 2 units placed next to each other may report different readings. This is a normal occurrence with digital sensors and should not be considered a defect.

4. For maximum performance in normal conditions, good quality alkaline batteries are recommended. When temperatures are below 0°F, alkaline batteries can lose power resulting in a loss of remote transmission. If you reside in an area that experiences frequent temperatures near or below 0°F, lithium batteries are recommended to minimize the loss of transmission.

Transmission Collision

Signals from other household devices, such as doorbells, home security systems and entry controls, may interfere. This is normal and does not affect the general performance of this product. The transmission will resume once the interference recedes.

PRECAUTIONS

1. The base unit is intended for indoor use only. It is not sealed against moisture and could be damaged if used outdoors.
2. Do not immerse the units in water. If you spill liquid on one, dry immediately with a soft, lint-free cloth.
3. Do not clean the units with abrasive or corrosive materials. This may scratch plastic parts and corrode electronic circuits.
4. Do not subject units to excessive force, shock, dust, temperature or humidity. This may result in malfunction, shorter electronic life span, damaged batteries or distorted parts.
5. Do not tamper with the unit's internal components. Doing so will invalidate the warranty on this product and may cause damage. The units contain no user-serviceable parts.
6. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries. Do not dispose of batteries in fire. Batteries may explode or leak. Remove the batteries if the units will not be used for a long period of time.
7. This product is for measuring weather temperatures only. DO NOT PLACE UNITS INTO OVENS, GRILLS, FREEZERS or MICROWAVE OVENS.
8. Always read the instruction manual before operating this product.

Important: Though the remote sensor is weather proof, it should be placed away from direct sunlight, rain, snow and should never be submerged in water.

SPECIFICATIONS

Indoor temperature range: 32°F to 122°F (0°C to 50°C)

Outdoor temperature range: -40°F to 158°F (-40°C to 70°C)

Resolution: 0.1 degree for temperature

Minimum/Maximum temperature records

12/24 hour clock

Low Battery Indicator

Transmission: Maximum 100 feet (30 meters) in open area

Power: 2 AAA batteries (not included) for base unit and 2AAA batteries for remote sensor (not included)

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications made to this device not expressly approved by FUZHOU SUNNY ELECTRONIC CO.,LTD. may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.