

Caution

Please read all warnings for your safety and optimal user experience. Please read and follow these instructions carefully and retain for your records.

1. Do not disassemble or throw into fire or water.
2. Do not expose to extreme weather conditions.
3. Do not use this product if you observe visible defects.
4. Do not short circuit the product or store it in a receptacle where it may be short circuited by other metallic or conductive objects.
5. Do not operate the product if it has been wet or otherwise damaged, to prevent against electric shock, explosion and/or injury.
6. Never attempt to dismantle the unit.
7. Children should be supervised to ensure that they do not play with the product.
8. Always disconnect the device when not in use.
9. Do not use if broken, damaged, or exposed to liquids.
10. Not to be used in extremely high ambient temperatures.
11. Do not use with damaged or faulty accessories.
12. Do not place near any sources of heat, open flame or liquid.
13. Disposal of a battery into fire or a hot oven, mechanically crushing or cutting of a battery, can result in an explosion.
14. Leaving a battery in an extremely high temperature can result in an explosion or the leakage of flammable liquid or gas.
15. The power bank will generate heat when charging. Always charge in a well-ventilated area. Do not charge under pillows, blankets or on flammable surfaces.
16. Do not subject the power bank to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy objects on the power bank.

Cygnett takes no responsibility for damages caused by incorrect use of its products.

Complies with
IMDA Standards
DA104966

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to connect the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separate between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.




This symbol on the product indicates that this product shall not be treated as household waste. Instead it shall be sent to the applicable collection point for the recycling of electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health. For more information about the recycling of this product, please contact your local city office.



CYGNETT

CHARGE UP SWIFT (GEN 2)
10,000mAh

USER MANUAL



Recharge your ChargeUp Swift

To recharge your ChargeUp Swift, connect it to a computer, car-charger, or wall-charger via the USB-C input (F), using the USB-A to USB-C cable provided. When charging, the LED's on the Digital display (B) will begin to flash, indicating remaining charge.

Charge Your Device Wirelessly

To charge your device, place it over the wireless charging output (C), and press the power button to turn on the power bank (A). Your device will start charging wirelessly after a few seconds. If your device does not start to charge after 10 seconds try to re-align it into the center of the power wireless charging symbol.

Charge Your Device via USB

Using your device's USB charging cable (not included), connect your device to any of the USB-A Outputs (D/E) or USB-C Output (F). Press the power button (A) once to start charging your device. Your device should indicate that it has begun to charge. The LED display (B) will now indicate your remaining charge. A second device can be connected without needing to press the button. When you are finished charging your device/s, detach the from your ChargeUp Swift and the power bank will turn off automatically.

Digital Charge Indicator

To check your remaining charge, press the power button (A) once. The LED display (B) will show the remaining charge represented by 4 white dots with each dot indicating 25%.

Product Specifications

Name	ChargeUp Swift 10K Gen 2 (P)
Item Number	CY4432PBCH
Wireless Output	10.0W, 7.5W, 5.0W
USB-C Output	5.0V-3.0A (15.0W), 9.0V-2.22A(20.0W), 12.0V-1.5A (18.0W)
USB-A Output 1	5.0V-3.0A (15.0W), 9.0V-2.0A(18.0W), 12.0V-1.5A (18.0W)
USB-A Output 2	5.0V-3.0A (15.0W), 9.0V-2.0A(18.0W), 12.0V-1.5A (18.0W)
USB-C Input	5.0V-3.0A (15.0W), 9.0V-2.0A(18.0W), 12.0V-1.5A (18.0W)
Micro-USB Input	5.0V-2.0A (10.0W), 9.0V-2.0A(18.0W), 12.0V-1.5A (18.0W)
Total Output	15.0W
Working Frequency Band	112kHz-205kHz
Max Output Power	2.8dB μ A/m@10m
FCC ID	2AEDZCY4432