

SHARPER IMAGE® RECHARGE ALARM CLOCK

CONGRATULATIONS ON YOUR NEW RECHARGE ALARM CLOCK.

Please read all instructions and warnings prior to use. Keep this manual as it contains important information for future reference.

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ BEFORE USE

- Not a children's item. Keep out of reach of children.
- Keep this device at least 8 inches (20 centimeters) away from cochlear implants, pacemakers, and other implanted medical devices.
- Keep all cards with magnetic strips away from the wireless charging pad.
- Do not expose to extreme temperatures or moisture.
- Do not expose to direct sunlight for extended periods.
- Do not use with attachments of any kind other than those that may be included.
- Use this product only for its intended purposes.
- This product has no user-serviceable parts. Do not disassemble or attempt to repair.
- Thoroughly inspect the alarm clock regularly. If the alarm clock appears worn, frayed, splintered, cracked, or broken in any manner, discontinue use and discard immediately.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WHAT YOU GET

- Recharge Alarm Clock
- USB-C Power Cable





GETTING STARTED

- Plug the USB-C power cable into the USB-C power input on the back of the alarm clock.
- Plug the other end of the USB-C power cable to a USB power outlet or into a USB power adapter (not included) and then plug the USB power adapter into a wall outlet.

Note: For full functionality, connect the alarm clock to a QC 3.0 or QC 2.0 USB power adapter or power source. Functionality will be limited if connected to 5V USB power adapter or power source.

LAYOUT



HOW TO USE

- To set the time, press the mode button and then press the plus (+) and minus (-) buttons to adjust the minutes. Press the mode button again and then press the plus (+) and minus (-) buttons to adjust the hours. Press the mode button a third time to finish setting the time.
Note: The alarm clock features a built-in battery to temporarily keep the time in the event of a power disruption or power outage. Reconnect the alarm clock to a power source as soon as possible to avoid having to set the time again.
- To set the alarm clock to 12-hour or 24-hour mode, quickly press the mode button twice. AM and PM will show on the display when the alarm clock is in 12-hour mode.
- To set an alarm, press and hold the plus (+) button for 3 seconds to activate the alarm and then press and hold the mode button for 3 seconds. Set the minutes using the plus (+) and minus (-) buttons. Press the mode button again and set the hours. Press the mode button again to finish setting the alarm.
- To remove a set alarm, press and hold the minus (-) button for 3 seconds.
- To stop your set alarm, press any button while the alarm is going off.
- To change the brightness of the display, press the plus (+) and minus (-) buttons.
- To power on the night light, press the night light button. Repeatedly press the night light button to cycle through the night light brightness levels.

WIRELESS CHARGING

- Place a compatible smartphone in the center of the wireless charging pad. The blue light will flash twice when charging starts and will stay on while charging. The max output of the wireless charging pad is 10W.
- Remove your device when the blue light turns off. Charging has finished.
- If the blue light flashes continuously, remove any objects on the wireless charging pad. The wireless charging pad has detected an object that is not connecting properly for wireless charging.

CARE INSTRUCTIONS

- Unplug the alarm clock before cleaning.
- Wipe clean with a soft, non-abrasive dry cloth. Do not expose the alarm clock to water or other liquids.

SHARPER IMAGE® NAME AND LOGOS (CLUDING THE LOGO) ARE TRADEMARKS OR REGISTERED TRADEMARKS DISTRIBUTED BY AND ©2023 MERCYSOURCE, LLC. IRVINE, CA 92618. ALL RIGHTS RESERVED.

FOR CUSTOMER SUPPORT, PLEASE CALL
1-800-341-274.

Model No: xxxx

Printed in China

WARNING

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.