



## User's Guide for Battery WiFi Video Doorbell




Charge LED: Charging in Red; Full in Green.


**Step 1:** Open the battery cover.



**Step 2:** Install 18650 battery and Mirco-SD.



**Step 3:** Drill four holes in your wall, and install the anchors.




## Product Specification Sheet

Lens	DFOV/130° Wide-angle lens (4Glass)
Infrared LEDs	6pcs Infrared LEDs with 5 meters flash distance
PIR Motion Sensor	3 meters PIR distance
Storage	Up to 128GB Micro SD card
Connectivity	802.11b/g/n Wi-Fi@2.4G
Power consumption	Standby 200uA Working 260 mA
Battery	Two 18650 specification batteries
Wi-Fi distance	80 meters (open space without obstacle) 15 meters (indoor)
Limited distance between doorbell and chime indoor	20~30 meters
Video Compression	H.264
Voice Intercom	Two-way audio with noise cancellation
Video resolution	1080*720@30 fps
Notifications	Push Notifications within 5-8 seconds


Device Wakeup	Within 4-7s
Working Temperature	-10~55°C
Storage Temperature	-20~60°C

## Install your doorbell


A brief introduction of the Doorbell.



**Step 4:** Fix the doorbell on the wall through fixing screw hole.




**Step 5:** Mount doorbell in the direction of the arrow and lock it by the screws at the bottom.



**Step 6:** Press the Reset button long until you hear the "system reset" prompt from the doorbell speaker.

## Indoor chime user manual



### Volume settings

Press the "volume" button once to trigger one time. There are 4 volume levels you can choose from low to high.

### Change the ring

**Step1:** Press the "ring" button to choose one you like. The indoor chime offers 38 different kinds of music for options. Each press changes the music.

**Step2:** Press the "volume" button for 5 seconds till the music changes.

**Step3:** Press the doorbell button to match the indoor chime. Now, the music changed.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.