

A Power Indicator	F Group Button	K Beep Button
B Power Button	G Modeling Lamp Button	L Hot Shoe Interface
C LCD Screen	H Test Button	M Micro USB Port
D Sync Mode Button	I Power Adjust Buttons	N Battery Cover
E TTL/Manual Button	J Channel Button	P Battery Compartment



Turning the Unit On and Off	Modeling Lamp	Beep																																																																																	
<ol style="list-style-type: none"> 1. Install AAA batteries. 2. Press and hold the power button B for 2 seconds to turn the unit on and off. 	Press G once to set modeling lamp to 50% brightness, once again to set modeling lamp to 100% brightness, and a third time to turn the modeling lamp off.	Press K to toggle audible remote adjustment and recycle tone on and off.																																																																																	
Setting Groups and Channels	Select a shooting mode (manual or TTL)	Select a sync mode (1st, 2nd, HSS)																																																																																	
<p>Press the J to toggle through channels 1-8.</p> <ul style="list-style-type: none"> • both the S1 and the TTL remote must be on the same channel • setting the channel to “-” will disable all radio communication <p>Press F to toggle through groups A-C.</p> <ul style="list-style-type: none"> • assigning groups allows you to individually control the lights via the TTL remote 	Press E to toggle between Manual and TTL mode.	Press D to toggle between 1st-curtain, 2nd-curtain, and High Speed Sync modes.																																																																																	
<p>Note: HSS is only available in Manual mode, not TTL mode.</p>		<p>Note: Nikon users switch between 1st- and 2nd-curtain sync via the camera and enable HSS by increasing the shutter speed on their camera with Auto FP mode enabled.</p>																																																																																	
Tech Specs	Firmware Upgrade Instructions																																																																																		
<ol style="list-style-type: none"> 1. frequency: 2.4GHz 2. voltage: 2.2-3.4Vt 3. sync speed: 1/8000s 4. wireless range: ≤20 meters 5. 24Channels <table border="1"> <tr> <td>A</td> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> <td>7</td> <td>8</td> </tr> <tr> <td>Channel</td> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> <td>7</td> <td>8</td> </tr> <tr> <td>Frequency</td> <td>2401</td> <td>2402</td> <td>2403</td> <td>2404</td> <td>2405</td> <td>2406</td> <td>2407</td> <td>2408</td> </tr> </table> <table border="1"> <tr> <td>B</td> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> <td>7</td> <td>8</td> </tr> <tr> <td>Channel</td> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> <td>7</td> <td>8</td> </tr> <tr> <td>Frequency</td> <td>2401</td> <td>2402</td> <td>2403</td> <td>2404</td> <td>2405</td> <td>2406</td> <td>2407</td> <td>2408</td> </tr> </table> <table border="1"> <tr> <td>C</td> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> <td>7</td> <td>8</td> </tr> <tr> <td>Channel</td> <td>1</td> <td>2</td> <td>3</td> <td>4</td> <td>5</td> <td>6</td> <td>7</td> <td>8</td> </tr> <tr> <td>Frequency</td> <td>2401</td> <td>2402</td> <td>2403</td> <td>2404</td> <td>2405</td> <td>2406</td> <td>2407</td> <td>2408</td> </tr> </table> <p>Note: Remote has A,B,C three groups, and eight channels of these three groups are identical, they are in different flash intensity.</p>	A	1	2	3	4	5	6	7	8	Channel	1	2	3	4	5	6	7	8	Frequency	2401	2402	2403	2404	2405	2406	2407	2408	B	1	2	3	4	5	6	7	8	Channel	1	2	3	4	5	6	7	8	Frequency	2401	2402	2403	2404	2405	2406	2407	2408	C	1	2	3	4	5	6	7	8	Channel	1	2	3	4	5	6	7	8	Frequency	2401	2402	2403	2404	2405	2406	2407	2408	<p>visit our website at interfitphotographic.com for firmware updates for new features & fixes</p> <ol style="list-style-type: none"> 1. Take out all batteries from P the battery compartment 2. Insert the micro USB cable into the remote's micro USB M port 3. Long-press B the power button while connecting the cable to your computer 4. Release the power button B when the remote has been recognized as a USB device 5. Start the firmware upgrade application and click connect, then start. 6. When pass is displayed, click disconnect. 	
A	1	2	3	4	5	6	7	8																																																																											
Channel	1	2	3	4	5	6	7	8																																																																											
Frequency	2401	2402	2403	2404	2405	2406	2407	2408																																																																											
B	1	2	3	4	5	6	7	8																																																																											
Channel	1	2	3	4	5	6	7	8																																																																											
Frequency	2401	2402	2403	2404	2405	2406	2407	2408																																																																											
C	1	2	3	4	5	6	7	8																																																																											
Channel	1	2	3	4	5	6	7	8																																																																											
Frequency	2401	2402	2403	2404	2405	2406	2407	2408																																																																											

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.