

**Magnetic Wireless Power Bank
with Watch Charger**

V1.0

USER MANUAL

Specifications

Battery Capacity	10000mAh 38.5Wh
Type-C Input	12V= 1.5A, 9V= 2A, 5V= 3A
Type-C Output	12V= 1.67A, 9V= 2.22A, 5V= 3A
USB Output	12V= 1.5A, 9V= 2A, 5V= 4.5A
Type-C Cable Input	12V= 1.5A, 9V= 2A, 5V= 3A
Type-C Cable Output	12V= 1.67A, 9V= 2.22A, 5V= 3A
Lightning Cable Output	12V= 1.5A, 9V= 2A, 5V= 3A
Wireless Output	15W / 10W / 7.5W / 5W
Watch Charger	2.5W
Dimensions	122.9 x 76.5 x 23.8mm

Package Contents



Power Bank x1




Charging Cable x1



User Manual x1


Product Features



1. Digital Display
2. USB Output
3. Type-C Input & Output
4. Power Button
5. Watch Charger
6. Wireless Charger for Phone and Magnetic Adsorption Ring
7. Built-in Type-C Cable Input & Output
8. Built-in Lightning Cable Output
9. Hidden Phone Stand

Operating Instructions

1. Charging the Power Bank



- 1). Connect the Type-C cable (included) between power bank and the wall charger or power adapter (not included), It will start charging automatically. Built-in Type-C cable can directly charge the power bank. It's recommend to use the PD18W wall charger or power adapter to match the fast charging.
- 2). Fully charge the power bank before using the power bank for the first time. Recharge the power bank once every three months when not in use or seldom used.
- 3). During charging the power bank, the digital display will flash and indicate the available battery capacity percentage. If it is fast charging, the icon will light up. When fully charged, the digital display will be 100.
If the digital display does not match the actual battery level, please use or discharge it to 00. and then charge it to 100. After 2 or 3 discharging and charging cycles, The digital display will accurately indicate the battery level.

2. Charging the device



1). Wired charging

Press the power button, the digital display is on. Connect the charging cable between the power bank and your device to start charging. Built-in Type-C cable and Lightning cable can directly charge the device after pressing the power button.

During charging the device, the digital display is always on. If it is fast charging, the icon will light up.

2). Wireless charging for phone

Place the device in the center of the wireless charging area. If your device supports MagSafe technology, The power bank will automatically hold it thanks to strong magnets.

Press the power button, the digital display is on, the icon will light up, which means wireless charging is in progress. If it is fast wireless charging, the icon will light up.

P.S., Make sure your smartphone is fit for Qi standard receiving equipment.

3). Wireless charging for Apple watch or Samsung Watch

Place the watch in the center of the watch charger. Press the power button, It will start charging the watch. During charging the watch, the digital display is on.

Troubleshooting

1. If the digital display does not match the actual battery level, please use or discharge it to 00. and then charge it to 100. After 2 or 3 discharging and charging cycles, The digital display will accurately indicate the battery level.
2. Press the power button, If the digital display is 00, It means the battery is running out, please recharge immediately.
3. This power bank can automatically identify equipment that need to charge, If no device is being charged, the power bank will be turned off after 30 seconds.
4. For wireless charging, your device must be equipped with a Qi wireless receiver. The device can automatically identify a Qi-compatible device placed on it. If the center point of the receiving terminal is deflected over 8mm from the center point of transmitting terminal, the power bank will turn off automatically.
5. If wired charging is not working properly, please change a charging cable, since the connector may become loose due to wearing.
6. During charging, the device may become warm due to high

currents and resistance, especially during wireless charging. To reduce temperature, avoid running intensive applications or using GPS on your mobile device when charging.

Cautions

1. The power bank will generate heat when charging. Always charge in a well-ventilated and open-air area.
2. Do not charge under pillows, blankets or on flammable surfaces. Keep the power bank away from heat sources, direct sunlight, combustible gas, humidity, water or other liquids.
3. Do not disassemble, open, microwave, incinerate, paint or insert foreign objects into the power bank.
4. Do not subject the power bank to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy objects on the power bank.
5. Do not short-circuit the power bank or store it in a receptacle where it may be short-circuited by conductive objects.
6. Do not operate the power bank if it has been wet or damaged, to prevent against electric shock, explosion and/or injury.
7. Keep the power bank dry to avoid short circuits or other damage to electronical components.
8. Keep the power bank away from high heat and flammable liquids and gasses. Avoid using in environment temperature above 45°C or below 0°C.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.