

Gogoro 2 (Smartscooter™)user manual (ECU)

Product name :	Wireless function	Detail
ECU	BTLE	Short press : Unlocked scooter Long Press : Open trunk
	NFC	Communication battery and scooter

Unlocking

If your Smartscooter™ is locked, press the button on the iQ System™ Smart Key to unlock it. The headlight and taillight will flash, an audible tone will sound, the handlebar will be unlocked and the dashboard will light up to confirm the unlocking command.

Locking

If the Smartscooter™ is unlocked, press the button on the iQ System™ Smart Key to lock it. The headlight and taillight will flash, an audible tone will sound, the handlebar will be locked and the dashboard will dim to confirm the locking command.

Opening the luggage compartment

1. If the Smartscooter™ is locked, press and hold the button on iQ System™ Smart Key for 2 seconds to open the seat and unlock the luggage compartment.
2. If the Smartscooter™ is already unlocked and not on the move, press and hold the button on iQ System™ Smart Key for 2 seconds, or press the  “seat opening” button to open the seat and unlock the luggage compartment.

Replacing batteries

1. Park the scooter firmly beside a GoStation®. Extend the side stand, or hold the brake lever down and lightly press the  “GO” button, to shut off the motor.
2. Open the seat. Hold the handle of one of the Gogoro® batteries to pull it out.
3. Insert the battery into an empty GoStation® slot and push it all the way until it's locked and you hear a confirmation sound.
4. When the screen says “Please insert your other battery” repeat the instructions in Step 2 and 3.
5. Two fresh batteries will pop out a few seconds after you successfully returned the drained ones.
6. Insert the fresh batteries into your scooter, put down the seat and wait for the  warning symbol to disappear; when it's done, unlock the scooter and you are ready to roll. (Please refer to chapter 3 for unlock and turn motor into Standby Mode instructions.)



Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance **20cm** between the radiator & your body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.