

1. Remote Control Functions

1> Button A: Locks the scooter. The scooter will sound an alarm. If you step on the scooter's platform it will not balance once Lock Mode has been activated.

2> Button B:

(1) If your Wind Rover scooter is in Lock Mode, press B and it will switch to Unlock Mode.

(2) If your Wind Rover scooter is in Unlock Mode, press B and it will switch to Towing Mode. When the scooter's battery power low, i.e. less than 25%, you can use Towing Mode to effortlessly tow the scooter home.)

(2) When in Towing Mode, press B to cancel Towing Mode and the scooter will return to Unlock Mode.

3> Button D: Switches Speed Modes. Press D once, the scooter sounds one beep for Beginner Mode (max speed 8km/h), or sounds two beeps for Normal Speed Mode (max speed 18km/h).

4> Button C+D: Pressing buttons C+D together rebalance the scooter. In Unlock Mode, adjust the level then press Buttons C+D at the same time. The scooter will sound two beeps and rebalance itself to its default position. Use this function if the scooter is leaning slightly.

5> Button E: Button E locks and unlocks the remote control key fob.

NOTE: You can switch the scooter off when it is in Lock or Unlock mode. The scooter will remember the final mode (lock/unlock) and set it as its default mode. When you start the scooter again it will remember its last mode.



Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by SHANGHAI ASCENT INTERNATIONAL CO.,LTD may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.