

# Instruction Manual E-F15



# **Safety Precautions:**

Repairing and installation of this speaker cabinet must be carried out by qualified personnel following the approved safety standards.

Do not attempt to clean the plastic enclosure with solvents or petrochemical based cleaners.

Do not place objects which are sources of heat on the speaker cabinet such as lighting equipment or smoke machines.

Do not expose the speaker cabinet to direct rain or stand in water. Liquid getting into the box will risk a short circuit and will be hazardous.

Do not stack the speaker cabinet in a manner that could cause injury should a cabinet become dislodged.

# Additional precautions for Auto-amplified devices of the series.

Before installation, ensure that the voltage and frequency of power outlet matches the power requirements of the loudspeaker.

Disconnect from mains power before making a signal connection to the loudspeaker.


Make sure that the power-cord is never crimped or damaged by sharp edges. Never let the power-cord come into contact with other cables. Only handle the power-cord by the plug.

If external fuse needs to be replaced, ensure it is replaced with the identical rate and dimension fuse.



This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product

# **Built-In Amplifier Panel**



1. MP3 player: USB/SD input + FM+ Bluetooth

MODE	Exchange between USB / SD /Bluetooth/FM
M	Play/Pause
EQ	Music Play Types
FD-	Last File Display
FD+	Next File Display
Ð	Repeat
<b>*</b>	Last Song
<b>&gt;&gt;</b>	Next Song

Rear Panel Controls.

- 1. SD CARD SLOT: Insert your standard SD card here.
- 2. DISPLAY SCREEN: Display track information.
- 3. USB MEMORY STICK SLOT: Connect your USB memory stick here.
- 4. MODE: Select the input source SD card USB or Bluetooth® and turn OFF the player.
- 5. PLAY/PAUSE: Use this control to play or pause your MP3 music/backing track.
- 6.EQ:Select music play types
- 7.FD-:Select last files display
- 8.FD+:Select next file display
- 9. LOOP: Use this to enable/disable the looped playback mode.
- 10. REWIND: Press to skip to the preceding track.
- 11. FORWARD: Press to skip to the next track.
- 12. a. CONNECT TO BLUETOOTH® DEVICE: Toggle through the system modes and select Bluetooth® (using MODE switch.)
  - b. On your Bluetooth® capable device, make sure Bluetooth® is enabled. Scan down the list of available devices search for: BT and select.
  - c. Your Audio is now connected to your Bluetooth device.

## 2. MIC/LINE Input:

MIC INPUT: A balanced input for low level, low impedance devices eg. -mic (200-600ohms) or electro-acoustic guitar.


LINE INPUT :An unbalanced input - for higher output line level devices eg. - keyboard, processor, drum machine.

- 3. L: Left Channel
- 4. R: Right Channel
- 5. VOLUME Master: Controls the overall level of your audio.
- 6. MP3: Press In can play MP3
- 7. OUTPUT: A BALANCED signal feed that is picked up before the power amp stage. This can be used to connect to a second Audio cab (daisy chained), active wedge monitor, house PA or mixing console for example.
- 8. LINE/MIC: Transfer LINE Input and Microphone Input

- 9. LIMIT Light: Illuminates just before the amplifier begins to clip. Adjust the level controls and signal level from your source so this illuminates only briefly on peaks in the music.
- 10.SIGNAL Light: This will illuminate when the unit is inputting the signal.
- 11. POWER Light: This will illuminate when the unit is powered up. There is also a second power LED on the front of the cab which will illuminate to indicate that power is present.
- 12. AUX INPUT: This gives you the option to connect an additional line level device. Control the Level with Level control. Please use a stereo cable.
- 13.VOLTAGE: The model unit has dual voltage 120V/240V, and sets at 120V. When you use 220~240V, you should change to 240V side.
- 14. MAINS SWITCH: Turns the system on and off. Ensure the level controls are at minimum when switching on and off.

MAINS INLET SOCKET AND FUSE: IEC input for connection of an appropriate mains lead.

# Remote Control:



# **Functions:**

- 1. Stop the MP3 player
- 2. Switch between USB / SD /Bluetooth
- 3. Mute the sound of the MP3 player
- 4. Skip to previous track
- 5. Skip to next track
- 6. Play/Pause MP3 player
- 7. Decrease volume
- 8. Increase volume
- 9. EQ to control the tone level
- 10. Choosing music by numbers

## **FCC Caution.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

# Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between thee quipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

# \* RF warning:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.