


USER GUIDE



WALL SWITCH



Wall switch NodOn®

Reference: CWS-3-1
Radio frequency: 868MHz

Reference: CWS-3US-1
Radio frequency: 908MHz

Power supply: CR2032 battery
Range up to 80 meters outdoor
Range up to 40 meters indoor
Operational temperature: 0°C / 40°C

IP20

Radio protocol: Z-Wave Plus® (500 series)
Dimensions: 80 mm (L) x 80 mm (I) x 15 mm (h)
Weight: 52 g
Warranty: 2 years

The NodOn® wall switch can be added and operated in any Z-Wave® network with other Z-Wave® certified devices from other manufacturers and/or other applications.

All non-battery operated nodes within the network will act as repeaters regardless of vendor to increase reliability of the network.

It has 2 distinctive working modes:

1. «STANDALONE» MODE


The wall switch can control Z-Wave® compatible devices directly, such as the NodOn® Smart Plug or a light dimmer, whoever is the manufacturer.

Note: No home automation gateway is involved and necessary in this mode.


2. «GATEWAY» MODE

The wall switch is in "Gateway" Mode as soon as it is added in a Z-Wave® network managed by a home automation gateway. The wall switch becomes then the gateway's assistant, capable to launch up to 16 different scenes through it (SCENE Profile) or directly associated to your Z-Wave® compatible devices (MONO or DUO Profile).

The wall switch can be screwed (screws not included) or bonded thanks of the adhesive tape included.




When you put in place your wall switch on a plane surface, make sure that the battery holder is on the bottom part.



PUTTING INTO SERVICE

For the first application, take care to remove the battery protector.




BATTERY CHANGE

The wall switch NodOn® works thanks to a CR2032 battery (included).

In order to change the battery, detach the frame of the wall switch and pull out then the two buttons from their support.



Slide the battery with your thumb without pull on the battery contact holding the battery.



Careful: If you pull too much on the battery contact in order to change the battery, you risk to break it.

WALL SWITCH INTERFACE


The wall switch has 4 buttons and one LED located on the top of the product.



BATTERY LEVEL

In order to know the battery level, a simultaneous short press on 1 and 2 must be performed. The LED will display the battery level according to below table:


LED state	Battery level
Green	Above 50%
Orange	Between 50 and 20%
Red	Below 20%



FACTORY RESET

A factory reset will completely delete the memory of the wall switch and restore all the parameters to default value.

A simultaneous long press (1 sec) on 3 and 4 will perform this factory reset.



The LED will blink red and green to validate the reset

Careful: In "Standalone" Mode, make sure to remove all the devices added or associated in the wall switch's network before performing a factory reset.

In "Gateway" Mode, use the factory reset procedure only when the Primary Controller (i.e. the gateway) is missing or defective. Reset the wall switch does not mean that it has been removed from the Primary Controller memory. Remove the wall switch (through the Primary Controller) before performing a factory reset.

By default, the wall switch is in "Standalone" Mode. It means it can control compatible Z-Wave® devices without involving the gateway. The wall switch acts as the Primary Controller of the network.

While the wall switch is in "Standalone" Mode, you can:

- Control one or several devices (up to 8) with only 1 button: MONO Profile.
- Control one or several devices (up to 8) with 2 buttons: DUO Profile.

Careful: You must not unplug a Z-Wave® device definitely without removing it from the wall switch's Z-Wave® network first (See the "Exclusion" part below). This can have a serious impact on the battery lifetime.

ASSOCIATION

Careful: Before associating a device which was not recently bought, please perform an "EXCLUSION" first. Please refer to the "Exclusion" section below.

Association is performed in 3 steps:

1 Push 3 times (quickly) on the 1 button to activate the "Association" Mode.

The LED glows in blue

2 Choose which button will control your device, within 10 seconds.

- A short press on one of the buttons of the wall switch (1, 2, 3 or 4) will activate the MONO Profile. The pressed button will then control your device.
- A long press on the 1 button will activate the DUO Profile, combined with the 3 button. The 1 (ON) and 3 (OFF) buttons will then control your device.
- A long press on the 2 button will activate the DUO profile, combined with the 4 button. The 2 (ON) and 4 (OFF) buttons will then control your device.

The LED blinks in blue to confirm your choice

3 Place the device you want to associate in "Learning" Mode, within 10 seconds. To do so, please refer to your device's user guide.

Careful: The LED of the wall switch blinks green to confirm the association process

Careful: In case of a too long association process or others problems during the process, the LED will blink red. Please restart the procedure. Once the association is validated, your wall switch is able to control your device. Different actions are possible.


1. MONO PROFILE

This profile allows controlling your associated device(s) using just a single button of the wall switch.

A short press on 1, 2, 3 or 4 (depending on your choice during association process) will activate (ON) your associated device(s), a second short press will deactivate (OFF) your associated device(s).

If your device has dimming features (light dimmer, roller shutter, etc.):

- A long press on the 1, 2, 3 or 4 (depending on your choice during association process) will dim up your associated device (light, roller shutter, etc.) until you release the button.
- A second long press on the same button will dim down your associated device (light, roller shutter, etc.) until you release the button.



2. DUO PROFILE

This profile allows controlling your associated device(s) with two mutual buttons.

- A short press on 1 (or 2) depending on your combination choice during association process will activate (ON) your associated device(s).
- A short press on 3 (or 4) depending on your combination choice during association process will deactivate (OFF) your associated device(s).

If your associated device(s) has dimming features (light dimmer, roller shutter, etc.):

- A long press on 1 (or 2) depending on your combination choice during association process will dim up your associated device (light, roller shutter, etc.) until you release the button.
- A long press on 3 (or 4) depending on your combination choice during association process will dim down your associated device (light, roller shutter, etc.) until you release the button.



Careful: It is not possible to cumulate a MONO and DUO profile on the same button. Repeat the association process as many times as you want to associate a new device.

DISASSOCIATION

The disassociation deletes any association relationship between the device and the wall switch's buttons. However, your device will remain in your wall switch's Z-Wave® network.

1 Push 3 times (quickly) on the 2 button.

The LED blinks in blue

2 Place the device you want to disassociate in "Learning" Mode, within 10 seconds. To do so, please refer to your device's user guide.

The LED blinks in green to confirm the disassociation

INCLUSION

Inclusion allows adding a device into the wall switch's Z-Wave® network, without associating it with any buttons of the wall switch. The wall switch will then not be able to control your added device.

1 Push 3 times (quickly) on the 3 button.

The LED blinks in blue

2 Place the device you want to add in "Learning" Mode, within 10 seconds. To do so, please refer to your device's user guide.

The LED blinks in green to confirm the inclusion

onder meer de informatie in de technische gegevens, de veiligheidsinstructies en de instructies, Nodon garandeert geen ononderbroken of foutloze werking van het product. Nodon is niet verantwoordelijk voor eventuele schade als gevolg van het niet naleven van de instructies voor het gebruik van het product.

ES – GARANTIA - Nodon SAS, 121 Rue des Hêtres, 45590 ST CYR EN VAL Francia ("Nodon") garantiza el producto y los accesorios de la marca Nodon contenidos en el embalaje original contra defectos en materiales y mano de obra para un uso normal, de acuerdo con las normas de uso publicadas por Nodon, para un periodo de dos (2) años desde la fecha original de compra por el usuario final ("Periodo de Garantía"). Las normas de uso publicadas por Nodon incluyen pero no se limitan a la información contenida en las especificaciones técnicas e instrucciones de seguridad. Nodon no garantiza que el funcionamiento del producto sea ininterrumpido o libre de errores, Nodon no se responsabiliza de los daños derivados de no seguir las instrucciones de uso del producto.

MENTIONS LEGALES
RECHTLICHER HINWEIS
LEGAL NOTICE
JURIDISCHE MEDEDELING
AVISO LEGAL

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with radio frequency exposure limits set forth by the FCC for an uncontrolled environment.

NODON
NodOn SAS
121 Rue des Hêtres
45590 ST CYR EN VAL - FRANCE



IC Statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with radio frequency exposure limits set forth by the Industry Canada for an uncontrolled environment.

This device must not be co-located or operating in conjunction with any other antenna or transmitter. Cet équipement est conforme aux limites d'exposition aux radiofréquences définies par la Industrie Canada pour un environnement non contrôlé.

Ce dispositif ne doit pas être utilisé à proximité d'une autre antenne ou d'un autre émetteur.
CAN ICES-3 (B)/NMB-3(B)

EU Declaration of conformity

NodOn SAS hereby declare that this equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC, ErP 2009/125/EC Directive and RoHS 2011/65/EU. Declaration of conformity and test report on www.nodon.fr

WEEE

Your NodOn's product has been designed and manufactured using quality material and components, which can be re-used and recycled. The presence of the crossed-out wheeled bin symbol indicates that the product complies with EU Directive 2002/96/EC. It must disposed of through an appropriate collection and recycling structure. Please contact your local electrical and electronic equipment waste management scheme. Please respect your local municipal regulations and do not dispose of these products with unsorted household waste. The correct disposal of products at the end of their working life is good for the environment and your health.

FR – GARANTIE

NodOn SAS, 121 Rue des Hêtres, 45590 ST CYR EN VAL France ("NodOn") garantit ce produit et les accessoires, portant la marque NodOn, contenus dans l'emballage d'origine contre tout défaut matériel et de conception dans le cadre d'une utilisation normale conformément aux directives publiées par NodOn pendant une durée de DEUX (2) ANS, à compter de la date d'achat initiale par l'utilisateur final (la « Période de Garantie »). Les directives publiées par NodOn comprennent notamment les informations contenues dans les caractéristiques techniques, les instructions de sécurité et la notice. NodOn ne garantit pas une utilisation ininterrompue ou exempte d'erreurs du produit. NodOn décline toute responsabilité pour d'éventuels dommages découlant du non-respect des instructions applicables à l'utilisation de ce produit.

DE – GARANTIE

NodOn SAS, 121 Rue des Hêtres, 45590 ST CYR EN VAL France ("NodOn") übernimmt die Garantie für dieses Produkt und dessen Zubehör der Marke NodOn, die in der Originalverpackung enthalten sind. Die Garantie bezüglich jeglicher Material- und Herstellungsfehler gilt, wenn diese sachgerecht genutzt werden, entsprechend der von NodOn veröffentlichten Anleitung für einen Zeitraum von zwei Jahren, ab dem Datum, an dem das Produkt vom Endbenutzer im Einzelhandel erworben wurde (der „Gewährleistungszeitraum“). Die von NodOn veröffentlichten Richtlinien enthalten insbesondere die in den technischen Spezifikationen, Sicherheitsanleitungen und im Benutzerhandbuch enthaltenen Informationen. NodOn garantiert keine ununterbrochene oder fehlfreie Nutzung des Produkts. NodOn haftet nicht für mögliche Schäden, die durch die Nicht-Einhaltung der für das Produkt geltenden Anleitungen verursacht wurden.

EN – WARRANTY

NodOn SAS, 121 Rue des Hêtres, 45590 ST CYR EN VAL France ("NodOn") warrants the NodOn-branded hardware product and accessories contained in the original packaging against defects in materials and workmanship when used normally in accordance with NodOn's published guidelines for a period of TWO (2) YEARS from the date of original retail purchase by the end-user purchaser ("Warranty period"). NodOn's published guidelines include but are not limited to information contained in technical specifications, safety instructions and user guide. NodOn does not warrant that the operation of the Product will be uninterrupted or error-free. NodOn is not responsible for damage arising from failure to follow instructions relating to the product's use.

NL – WARRANTIES

NodOn SAS, 121 Rue des Hêtres, 45590 ST CYR EN VAL Frankrijk ("NodOn") garanteert het product en accessoires van het merk NodOn voorzien in de originele verpakking tegen alle materiaal- en ontwerp bij normaal gebruik in overeenstemming met de richtlijnen uitgevaardigd door NodOn voor een periode van twee (2) jaar vanaf de datum van aankoop door de eindgebruiker (de "Garantieperiode"). De door NodOn uitgegeven richtlijnen,