

MOULTRIE UNIVERSAL DIGITAL TIMER III | INSTRUCTIONS

MFG-15095

SET UP & CONTROL YOUR FEEDER: Program your feeder using either the built-in timer or the Moultrie App.

OPTION 1

PROGRAM FEEDER USING THE MOULTRIE APP (Recommended)

WHY USE THE APP?

These features are only available in the Moultrie App, and don't require a subscription:

- Sync feed times to local sunrise/sunset for automatic adjustments.
- Customize schedules to feed only on certain days of the week.
- Check estimated feed levels in the app.
- Run the feeder on demand.

HOW IT WORKS

Once your feeder is added to your Moultrie account, you can control your feeder via Bluetooth from up to 100 yards away. This allows you to adjust the feeder without disturbing the area, or feed on demand from your stand.

If you have an Edge 3 Series camera within range of your feeder, you can manage feed times remotely via cellular connectivity—from anywhere, anytime. (requires active camera subscription)

ADD YOUR FEEDER TO THE APP

- Download the Moultrie App from the App Store or Google Play.
- Sign up for an account or log in.
- Ensure the feeder kit is powered on.
- Open the Moultrie App and tap to link your feeder to your account when prompted.
- Set feed times and adjust settings directly in the app.



Program and monitor your feeder with the Moultrie App.
Scan to download the app and see product information.

FACTORY RESET

IF YOU NEED TO RESET THE TIMER:

- Hold **TEST** and the **DOWN** arrow at the same time. A 5-second countdown will begin.
- Continue holding until "rST" appears on the screen.
- The timer will reset to default settings.
- If your feeder was connected to your Moultrie App account, you will need to reconnect the feeder in the app and reprogram your settings.

OPTION 2

PROGRAM FEEDER USING THE TIMER

1. POWER ON THE TIMER

- Connect timer to power.
- Press any button to wake the screen.

2. SET LOCAL TIME

- The current time will appear on the display.
- Press **SET** to adjust the time. Current time will start flashing.
- Use the **UP/DOWN** arrows to adjust the local time. Press and hold the arrow to scroll faster.
- Press **SET** to save.

3. SET FEED TIMES

- The Universal Digital Timer III allows up to 10 feed times per day, with run times of 1-60 seconds each.
- DEFAULT SETTINGS:** If you do not set feed times, the feeder will run at 7:00 AM and 6:00 PM for 6 seconds.
- For each feed time, you will set:
 - Start Time** (when feed disperses)
 - Run Time** (how long the motor spins)
 - Motor Speed** (how far feed is dispersed)
- To program feed times, press the **UP** arrow to enter timer setup.
- The screen will display "TIMER 1."
- Press **SET** to begin programming this timer.
- Use the **UP/DOWN** arrows to select the desired time.
- Press **SET** to save.
- To program run-time, press **SET**.
- Use the **UP/DOWN** arrows to select the run-time.
- Press **SET** to save.
- To program motor speed, press **SET**.
- Use the **UP/DOWN** arrows to select **Hi/Med/Low**.
- Press **SET** to save.
- Repeat for additional timers.

4. RUN A TEST

- Press the **TEST** button.
- Stand at least 10 feet away.
- A 10-second countdown will begin, then the motor will spin.
- The test will run for the duration of TIMER 1.
- To cancel the test, press any button on the timer.

MOULTRIE UNIVERSAL DIGITAL TIMER III | INSTRUCTIONS

MFG-15095

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage;
(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Statement for FCC:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.

RF Exposure Statement for ISED:

This equipment complies with ISED exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.

Cet équipement est conforme aux limites d'exposition ISDE définies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur et la carrosserie.