 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2024-10-10
	System Instruction	Author:	Alexandria
Instruction of RF398C		Edition:	1.1
		Page 1 of 5	


## Instruction of RF398C



Figure 1 button of remote

### Item ZG button 12

Click the ZG button, the actuator moves to ZG position, stop when click any button during the

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2024-10-10
	System Instruction	Author:	Alexandria
Instruction of RF398C		Edition:	1.1
		Page 2 of 5	

movement;

Press and hold the ZG button for 5s, timer LED of remote flashes, the control box records current position as ZG position;

When in the process of moving to memory positions, the head and foot actuators move first, then the tilt and lumbar actuators move;

## 1.2 Antisnore button 14

Click 1.2 Antisnore button, actuators move to Antisnore position, stop when click any button during movement;

## 1.3 Reading button 15

Click Reading button, actuators move to Reading position, stop when click any button during movement;

## 1.4 Movie button 16

Click Movie button, actuators move to Movie position, stop when click any button during movement;

## 1.5 Head up 8


Press and hold HEAD UP button of remote, head actuator moves out, stop when released;

## 1.6 Head down 9

Press and hold HEAD DOWN button of remote, head actuator moves in, stop when released;

## 1.7 Foot up 10

Pressa and hold FOOT UP button of remote, foot actuator moves out, stop when released;

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2024-10-10
	System Instruction	Author:	Alexandria
Instruction of RF398C		Edition:	1.1
		Page 3 of 5	

### **1.8 foot down 11**

Press and hold FOOT DOWN button of remote, foot actuator moves in , stop when released;

### **1.9 tilt up 4**

Press and hold tilt UP button of remote, tilt actuator moves out, stop when released;

### **1.10 tilt down 5**

Press and hold tilt DOWN button of remote, tilt actuator moves in, stop when released;

### **1.11 lumbar up 6**

Pressa and hold lumbar UP button of remote, lumbar actuator moves out, stop when released;

### **1.12 lumbar down 7**

Press and hold lumbar DOWN button of remote, lumbar actuator moves in , stop when released;

### **1.13 Flat 17**


Click FLAT button, the bed goes flat, stop when click any button during the process of going flat;

### **1.14 Massage head 1**

Click MESSAGE HEAD button, head message motor switches message intensity, message intensityswitches among 0-1-2-3;

### **1.15 Massage foot 3**

Click MESSAGE Foot button, head message motor switches message intensity, message

 A Phoenix Mecano Company	Issue Department: Bedding Division	Date:	2024-10-10
	System Instruction	Author:	Alexandria
Instruction of RF398C		Edition:	1.1
		Page 4 of 5	

intensitieswitches among 0-1-2-3;

## 1.16 Massage time switch 2

Click MESSAGE time swtich button to swtich the time of massage form 10mins,20mins,30mins.

## 1.17 Ubb button 13

Click Ubb button, Turn on or off the underbed light.

### FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

Equipment generates,uses and can radiate radio frequency energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications.However,there is no guarantee that interference will not occur in a Particular installation.If thise quipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

	Issue Department: Bedding Division	Date:	2024-10-10
	System Instruction	Author:	Alexandria
Instruction of RF398C		Edition:	1.1
		Page 5 of 5	

### ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada' s licence - exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.