

## AP212663B/N User Manual

V1.5

Date: 2017-06-19

About AP212663, there are two models: type B and type N.

a. Package:

2 sets troffer light inside one box

- b. Installation:
  - 1. Turn off power
  - 2. Connect two lead wires (blue and brown) of troffer light and power line from the building (blue and brown) connected together one by one. Terminal block is not included. Installation must be performed by skilled technicians who are informed about the standards and technical requirements of the appliance and its proper Installation. Terminal block shall confirm to EN 60998-2-1 or EN 60998-2-2 or other approved terminals.

Type of terminal: screw or screwless

Number of terminals: 2

Rated voltage: min. AC100-240V

Rated connecting capacity: 0.75mm<sup>2</sup>

Necessary preparation of the ends of conductors: The wire ends of power cord need to be treated as clipping to avoid the separation of the wire ends.

3. Allocate Troffer light to the ceiling space for lighting and then turn on.



User guide for lighting control:

Type B:

The brightness and Color temperature is adjustable by APP. Right now, this APP is just support Andriod only, iOS is exclusive. Customer has to download BTSWAPP from Google Play first. The procedure showed below:

- 1. Key-in "Bluetooth AC Switch"
- 2. Start to search
- 3. Find it and follow installation instruction showed on windows.

Besides, QR code is another choice to access APP installation window directly.



User manual refer to "BTSWAPP user manual on Aesopower web site"

## Type N:

Troffer light can be turn ON and OFF by external power switch.

## Caution

- 1. Both models are for indoor use only.
- 2. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

3.

"The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person."



4. For AP212663 Type: B, reinforced insulation is maintained between LV supply and control conductors.

## FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.