IQAmerica_®

Entrance Alert Model WD5080

1x Magnetic piece, 1x Transmitter)

Installation instructions: Please retain for future reference.

This Package Contains:

- Plug-In Alert
- Magnetic Piece, Transmitter & CR2032 Lithium coin cell battery
- 4 screws and 4 wall plugs for mounting the Magnetic piece & Transmitter

You will require:

A small Phillips head and Flat head screwdriver

Installation Instructions

For interior use only

Please note: Installing the Transmitter or plug-in alert on or near metal structures or reinforced PVC doors or doorframes may reduce the transmission range.

Open the Transmitter and Magnetic piece as shown in Figure 1.

Remove the front cover by inserting a flat head screwdriver into the slot and twist gently.

LED Light (A)

Install the battery for Transmitter (Refer to Figure 2) Position the front cover as shown and slide the CR 2032 Lithium battery into the holder as shown, with the + side of

the battery facing you.

Install the Transmitter and Magnetic piece

Ensure the frame of the door or window is flat, clean and dry. Mount the bases using the screws and wall plugs provided (See Figure 3). Install both units vertically. Align the arrows make sure both the Magnetic piece and Transmitter are on the same level of surface (See Figure 1). Do not mount the Transmitter on or near large metal objects as this can

block signals from the wireless Transmitter.

Snap the front cover to the base. To

Snap the front cover to the base. To ensure a good alignment, adjust the front cover of the Magnetic piece by pushing or pulling the cover in and out (3 adjustment levels).




Figure 2

Transmitter

Figure 1


Align arrow for

Transmitter

installation


Install the Plug-in Alert (Refer to Figure 4)

Plug the Plug-in Alert into any 120 VAC outlet in the house. The Plug-in Alert must be within 150 feet of the Transmitter. The Plug-in Alert will play 2-note and 1-note sounds when it is first powered up.



Program Transmitter to the Plug-in Alert (Refer to Figure 5)

Program the Transmitter. Open the door or window. A Ding-Dong should be heard indicating the transmitter has been programmed to the Alert. Close the door or window. A Ding should be heard. The LED light (A) will illuminate indicating the transmitter is working.







Specification

Range.....up to 150 ft.

Electrical Load.........1 x CR2032 Lithium Battery for Transmitter

Note:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. To comply with FCC RF exposure compliance requirements, this device and its antenna must not be co-located or operated in conjunction with any other antenna or transmitter.

To Reset the Alert Programming, press and hold button B in Figure 6 until the plug-in chime sounds. The chime will play the tunes available indicating that previous programs have been erased. Return to the *Program Transmitter to the Plug-in Alert section* and repeat.



Figure 6

Troubleshooting

Alert doesn't sound when door or window is opened or closed

Check that the battery has been inserted correctly. The LED light should come on when the Transmitter moves closer to or away from the Magnetic piece.

Transmitter may be positioned out of range of the Plug-in Alert. Move the Plug-in Alert closer to the Transmitter.

A metallic object may be blocking the signal to the Plug-in Alert from the Transmitter position. Experiment with the location of the Plug-in Alert to see if you can move it to a more suitable place.

Battery in the Transmitter may need replacing.

The Transmitter LED will flash 5 times when the battery needs replacing. See instruction for Installing the Battery.

Note: In cold conditions, poor location or environment, operating at maximum range it is advisable to replace the battery more frequently (i.e. every 12-18 months) to maintain optimum performance.

Your Transmitter and Plug-in Alert haven't been programmed. Reset the automatic programming of your Plug-in Alert by pressing and holding down button B (Figure 6) for 5 seconds. The alert will sound indicating the programming has been erased. Program the Transmitter following the installation instructions.

For any other problem, call 1-800-296-1869 between 9am and 5pm EST.

IQ America Two Year Warranty

This is a "Limited Warranty" which gives you specific legal rights. You may also have other rights which vary from state to state and province to province.

For a period of two years from the date of purchase, any malfunction caused by

For a period of two years from the date of purchase, any malfunction caused by factory defective parts or workmanship will be corrected at no charge to you. To obtain a replacement, return the product to the place of purchase.

NOT COVERED: Repair service, adjustment and calibration due to misuse, abuse or negligence. Unauthorized service or modification of the product or of any furnished component will void this warranty. This warranty does not include reimbursement for inconvenience, installation, setup time, loss of use or unauthorized service.

This warranty covers only IQ America products and is not extended to other equipment and components that a customer uses in conjunction with our products.

This warranty is expressly in lieu of all other warranties, express or implied, including any warranty, representation or condition of merchant ability or that the products are fit for any particular purpose or use, and specifically in lieu of all special, indirect or incidental or consequential damages.

Repair or replacement shall be the sole remedy of the customer and there shall be no

Repair or replacement shall be the sole remedy of the customer and there shall be no liability on the part of IQ America for any special, indirect, incidental or consequential damages, including but not limited to any loss of business or profit, whether or not foreseeable. Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Retain receipt for warranty claims.

FCC Statement

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequence energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications. However, there is no guarantee that interference will not accor in a particular installation. if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an autlet on a circuit different from that to which the receiver is connectec.
- Consult the dealer or an experienced radio/TV technician for help.