

# User Manual

Elwing Board

Model No.: E1-500



**figure 1**

As shown in figure 1: the function of the battery pack for skateboard buttons. ON the left side of the silver switch for power switch and power display (built-in LED), according to ON open, play up to close OFF, the right to match the signal buttons and communication status display (built-in LED), when not connected, can open the switch first through tiny holes in series with a thimble normally ON press the switch when the LED is blue, when after the pairing LED flashing rapidly, and the left LED displays, followed by green, blue, red, red flash. Remote control principle with (matching method). When normal connection available remote control board line fast or slow speed skating, slide forward or backward, brake, etc.

Note:

- 1: after matching connection when the remote control to display power, otherwise not displayed.
- 2: good for rapid flashing signal, signal not shine for slow or not.

**FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

**RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.