


BleGateway

Instruction Manual

Product Description

BleGateway is a mini smart gateway that Tuya develops. It consists of a highly integrated Wi-Fi module, low power-consuming Ble Mesh module, and PCBA. It can be connected to the Tuya Smart app for device adding, reset, third-party control, and Ble Mesh group control, meeting smart home requirements.



Product Specifications

Product name	BleGateway
Input	5V $\equiv$ 1A (Direct current)
Working temperature	-10 $^{\circ}$ C ~55 $^{\circ}$ C
Working humidity	10%~90% RH (no condensation)
Dimensions	80x80x38MM
Wireless technology	Wi-Fi 802.11b/g/n
Radio frequency	2.400~2.4835GHz
Net weight	34g

Packing List

- BleGateway x 1
- Data cable x 1
- User Manual x 1



Preparation For Use

- In the App Store or Google Play, search for "Tuya Smart" or scan the QR code on the package/manual to download and install the smart App.





Operating Guide


1. Connect the Gateway with DC 5V power, the blue light will be on. Short press the gateway button, the blue light will be off.
2. Turn on the WLAN, Location of the mobile. And Enter into the TuyaSmart APP.
3. Click "Add Device", choose "Auto Scan", meanwhile press the Gateway button and hold for 5 seconds till the blue LED indicator on. Find the "BleGateway" and add it according to the APP instructions, see below screenshot:



4. Enter into the "BleGateway", click "Add device", then click "Add new device", start to discover the nearby smart lock, meanwhile, click "#" on the smart lock panel to awake it and then add successfully. See below screenshot:



5. Add successfully, you could open the smart lock remotely through BleGateway, see below screenshot:



This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.