



Fig. 1




RGB Remote control

Model No.:41617

FCC ID:2AMB5-CD14F

#### REMOTE:

To replace exhausted battery, slide the battery door on the back of the remote in the direction of the arrow. Insert 1 CR2032 battery, noting polarity. Replace cover by sliding in the opposite direction.



#### REMOTE OPERATION:

**NOTE:** Switch to "RF" for remote control functions (See Fig. 1).

1. On the remote, press the "on" button to turn the lights on. The default setting is white.
2. Pressing the "fade" button will slowly cycle through the spectrum of colors.
3. Press the "white" button to switch the lights back to white.
4. Use the "+" and "-" buttons to brighten or dim the lights.
5. The "r," "g" and "b" buttons stand for red, green and blue. These buttons allow you to either select one of these colors or blend them to select the desired color. Hold the "r," "g" or "b" button for three seconds to go directly to that color or press and release the button to move through the spectrum one color at a time.
6. The "save" button allows you to quickly return to your favorite color. Once the desired color is found, hold the "save" button until it flashes. The color will now be easily selectable by pressing the "save" button.
7. The "15," "30," "45" and "60" buttons automatically turn the lights off after the number of minutes indicated on the button.

#### MANUAL OPERATION:

1. Move switch to on position to turn the light on. The only color option in manual operation is white.
2. Move switch to off position to turn the light off.

#### MOUNTING INSTRUCTIONS:

**NOTE:** Mounting template is provided under the product.

**To mount light:** Remove battery cover and mount in desired location using screws and the included mounting template or double-sided tape. Reattach light to mounted

battery cover. Anchors are included for installing screws in the sheetrock.

**NOTE:** Battery door may remain mounted when changing batteries.

Functional range may be adversely affected by one or more of the following factors: weather, radio frequency interference, low transmitter battery or obstructions between the transmitter and receiver.

#### FCC STATEMENT:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.