



USER MANUAL

BO-F16V



Quick Start Guide

B0-F16V




Knowing Your Phone

Welcome to B0-F16V


To ensure safe use, please read the safety manual before using your device. Available features, services and applications may vary by device, software version, service provider and country. **B0-F16V** is not liable for performance issues caused by third-party applications.

Device Layout

Front Panel



Back Panel



Power key:

Press and hold to turn phone on/off. Press the button lightly to lock/unlock screen.

Volume key+/-:

Increase/decrease call volume, ringtone volume or media volume.

Images shown are for representation purpose only. **B0-F16V** retains the right to modify the content in this user guide without prior notice. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.


Inserting the SIM(s)

Your B0-F16V Smartphone has 1 micro SIM slot and 1 nano SIM slot to make it even more convenient to manage your calls all from one device.


1 - This is for your micro SIM.

2 - This is for your nano SIM.

T - This is for your TF.



Charging Socket



Charge the Battery

Simply connect the included Micro USB cable to the USB wall plug adapter and phone' s Micro USB port and plug in to start charging.

Before using the phone for the first time we recommend you charge the battery for a minimum of 3 hours. Simply connect the included Micro USB cable to the USB wall plug adapter and phone' s Micro USB port and plug in to start charging.

It is recommended that you use the included USB wall adapter to charge your phone, but if this is not possible, you can also charge the B0-F16V by connecting the cable to another suitable power source such as a USB port on a computer.

Charging times may vary. Once charged, you' re ready to start using your B0-F16V.

FCC Warning

Specific Absorption Rate (SAR) information SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this mobile phone has been tested and meets the FCC RF exposure guidelines

when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.0cm from the body.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not

installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

BOLTE
BO-F16V