


Charging and Power

☰ Quick Guide to NeuroTennis	
Overview of Buttons	>
Charging and Power	>
Pairing and Communication	>
NT Adjustments on the Court	>
Lesson and Drill Selection	>
Customizing Coaching Instructions, Drills and Lessons	>
Editing and Copying Coaching Instructions, Drills, and Lessons	>
Settings	>

< Charging and Power	
Charging	>
Powering On and Off	>

< Charging Done



Your NT200 can typically run for about 2.5 hours on a full charge. Actual duration will depend on factors such as coaching instruction frequency and volume level.

To charge your device:


1. If your device is on, turn it off by pressing and holding the power button for 3 sec.
2. Open charge port gently (see picture).

NOTE: Avoid getting moisture, clay, or dirt into the charge port.

3. Plug in Android-style Micro-USB charger (cable provided).
4. LED will blink while charging.
5. LED will turn solid when charging is complete.

While in use, NT will tell you if its battery level is low.

< Powering On and Off Done



hold for 3 sec.

1. To power on, press and hold power button for 3 sec.
2. LED will illuminate.
3. Listen for “NeuroTennis” announcement.
4. To play in partner mode, make sure both devices are on, and follow instructions for pairing devices under “Pairing”. For solo mode, just press “Play” to begin.
5. To power off, press and hold power button for 3 sec.