

NT Adjustments on the Court

Quick Guide to NeuroTennis	
Overview of Buttons	>
Charging and Power	>
Pairing and Communication	>
NT Adjustments on the Court	>
Lesson and Drill Selection	>
Customizing Coaching Instructions, Drills and Lessons	>
Editing and Copying Coaching Instructions, Drills, and Lessons	>
Settings	>

NT Adjustments on the Court	
Setting Volume	>
Setting Impact Sensitivity	>
Setting Coaching Instruction Frequency	>
Setting Coaching Instruction Source	>

<

Setting Volume

Done

1. First press of “volume” will state current level.

2. Press repeatedly to adjust from Low to Max.

3. Press again to mute.

NOTE: When muted, other keys will not function. NT will remind you that it is muted.

<

Setting Impact Sensitivity

Done

1. Press “Sensitivity” button repeatedly to adjust from Low to Max. Default is ‘high’.

<

Setting Coaching Instruction Frequency

Done

Coaching Instruction Frequency controls how often NT gives you coaching instructions after hits (yours, as well as your opponent’s). This is an average frequency, and NT randomizes coaching instructions, so you may sometimes hear several in a row, and sometimes hear none for several shots.

<

Setting Coaching Instruction Source

Done

Coaching Instruction Source determines whether NT announces coaching instructions when you hit, when your opponent hits, or both.

1. Press “Coaching Instruction Source” button repeatedly to cycle through the three options.

NOTE: If your device is not paired with another device, you will only hear the “my hits” option” and NT will remind you that it is unpaired.