

# Design Manual of AF-W12xTx Module Hardware

V1.1 2017.08

## Contents

1	Introduction.....	2
1.1	Abstract .....	2
1.2	Basic characteristics of module.....	2
1.3	Module type .....	2
1.4	Sketch map of module.....	3
1.5	Block diagram of hardware.....	4
2	Design issues of hardware .....	5
2.1	Power design .....	5
2.2	Reset pin.....	5
2.3	Reference circuit design.....	6
3	Application programming interface.....	7
4	Log serial port .....	8
5	Communication serial port.....	9
6	RF design and layout issues.....	9
6.1	RF selecting resistor.....	9
6.2	Directions for module layout .....	10
6.3	Advice on module layout .....	11
7	Purchase and support .....	12

### Patent statements

2017 99 IoT (Shenzhen) Co., Ltd. reserves all rights for this document. Any part of the document is not allowed to be reproduced, stored in any retrieval system or transmitted in any form that has not been unified in written form by 99 IoT (Shenzhen) Co., Ltd.

## 1 Introduction

### 1.1 Abstract

The document mainly lists the issues that need attention in all stages during the use of 99 IoT Wi-Fi module AF-W12xTx design by users in order to reduce design costs and increase product stability as far as possible.

AF-W12xTx is a complete and self-contained WiFi network solution module that can run either in MCU+WIFI mode or as a slave on other master MCU. The sensor and other applied specific devices can be integrated through GPIO port.


### 1.2 Basic characteristics of module

- Standard: 802.11 b/g/n 1x1
- Working mode: STA, AP, STA+AP
- Complete IoT solution (SDK, Cloud service, APP)
- Supporting Simple Configuration intelligent networking function (APP is provided)
- Supporting Amazon, Baidu cloud, Jingdong cloud, Ali cloud
- Each module has unique global MAC ID
- Antenna: outer antenna, IPEX antenna interface, onboard antenna
- Working ambient temperature: -20 to 85℃

### 1.3 Module type

Module name	Module description
AF-W121TI	PCB onboard antenna
AF-W121TO	IPEX outer antenna (optional)
AF-W123TI	PCB onboard antenna
AF-W123TO	IPEX outer antenna (optional)

## 1.4 Sketch map of module




引脚 Pin	名称 /主功能 Name/ main function	类型 Type	可选功能 Optional functions	其它功能 Other functions
1	GND			
2	Wi-Fi-ANTENA			
3	GND			
4	NC/GND			
5	CHIP_EN(RESET)	I		Reset
6	GPIOA_14	I/O	PWM0/ SWD_CLK	
7	GPIOA_15	I/O	PWM1/ SWD_DATA	
8	GPIOA_0	I/O	PWM2/EXT_32K/WL_LED	
9	GPIOA_12	I/O	PWM3	
10	GND			
11	VDD33			
12	GND			
13	VBAT_MEAS			
14	GPIOA_5	I/O	SDIO_SIDEHAND_INT/ PWM4	
15	GPIOA_18	I/O	UART0_RXD/SPI1_CLK /SPI0_CLK / I2C1_SCL / SD_D2/TIMER4_TRIG/ I2S_MCK	
16	GPIOA_19	I/O	UART0_CTS/SPI1_CS/SPI0_CS I2C0_SDA/SD_D3/TIMER5_TRIG I2S_SD_TX	

17	GPIOA_22	I/O	UART0_RTS / SPI1_MISO/ SPI0_MISO / I2C0_SCL SD_D0 / PWM5 / I2S_WS	
18	GPIOA_23	I/O	UART0_TXD/ SPI1_MOSI/ SPI0_MOSI / I2C1_SDA SD_D1 / PWM0	
19	GPIOA_30	I/O	UART2_Log_TXD/ I2C0_SDA/ PWM3 / RTC_OUT	
20	GPIOA_29	I/O	UART2_Log_RXD / I2C0_SCL PWM4	
21	GND			

Note:

- PIN19, 20 are for the use when Wi-Fi debugs LOG information input and output port.
- PIN19 of module AF-W121Tx needs to be pulled up to 3.3V externally, or floating, or to ensure that power-on time isn't low level.
- Please keep CHIP\_EN or other pins floating if they are not used.

## 1.5 Block diagram of hardware



## 2 Design issues of hardware

### 2.1 Power design

As shown in Figure 1.4 above

- (1) Input pin of main power supply is [PIN11], module supply voltage is DC 3.0 ~ 3.6, filter capacitor of 4.7-10uF needs to be placed near its location; loading capability of 3.3V power supply, the power supply with rated output current  $\geq 500\text{mA}$  is recommended.
- (2) Use of DC/DC powerchip: voltage output meets 3.3V and the maximum current output meets 500mA, input capacitor is as close as possible to voltage input pin, thickening ground wire width or grounded copper area, punching more via holes for different layers.
- (3) For LDO design, the voltage output meets 3.3V and the maximum current output meets 500mA, paying attention to device junction temperature, the formula of power consumption is  $PD=(V_{in}-V_{out}) * I_{load} + V_{in} * I_{GND}$ , in which  $V_{in}$  is input voltage,  $V_{out}$  is output voltage,  $I_{load}$  is load current,  $I_{GND}$  is ground current.
- (4) [PIN13] is ADC input pin, which can be used to detect battery voltage.

### 2.2 Reset PIN

As shown in Figure 1.4 above


- ( 1 ) [PIN5] is module reset pin: CHIP\_EN (RESET) , needs to be pulled up by connecting resistor of 100K $\Omega$  to power supply of 3.3V. The module will be in shutdown mode for low level.
- ( 2 ) If the module is not controlled by other MCU, the decoupling capacitor of 100nF is recommended to be added near its location to enhance the stability of the system.
- ( 3 ) If other MCU is needed to reset-control the module through the pin, a low pulse signal is needed and the duration of low level is at least 10ms.
- ( 4 ) If the voltage of power supply is unstable (lower than 3.0V), it may cause module halt.

It is recommended to add Brown out reset circuit, and the recommended chip is as follows:


**【ONSEMI/MAX809STR/SOT23/LM1117-3.3】** . It can also be monitored by other (master control) MCU.

## 2.3 Reference circuit design


Reference circuit design of module AF-W121Tx/AF-W123Tx, 5V to 3.3V conversion



5V to 3.3V conversion, LDO reference circuit design




Reset reference circuit design







## 4 Log serial port




( 1 ) PIN19 is a boot PIN:

Level	Function
0	Download image from UART
1	Boot from Flash

( 2 ) Serial port pinboard is used to observe output log by connecting abovementioned PIN to find abnormality of module software conveniently.

( 3 ) Serial port pinboard is used to achieve AT Command operation by connecting abovementioned PIN.


( 4 ) Serial port pinboard is used to achieve firmware programming by connecting abovementioned PIN.






## 5 Communication serial port

In general, it is recommended to communicate with other MCU through this serial port, the pins which need to be connected are shown in following figure: [PIN16], [PIN17] are optional. These two pins are used to achieve fluid control.



## 6 RF design and layout issues

### 6.1 RF selecting resistor




## 6.2 Directions for module layout

- ( 1 ) When using onboard antenna, layout forbidden area is seen in the figure below;
- ( 2 ) The module must be placed vertically with the onboard antenna top located or the module is placed horizontally with component side up;
- ( 3 ) When the module is placed vertically, the clear height of module's both sides is at least over 12mm;

When the module is placed horizontally, the clear height under the module is over 6mm;


Cable and other metals are prohibited above the module;

- ( 4 ) Neither can copper be cladded nor can metal devices, sensors, interference sources or other materials that have an impact on signal be placed under the layout forbidden area.



## 6.3 Advice on module layout

When users use the module with onboard PCB antenna, they can put the module in the following areas of the baseboard, or place the antenna of module outside the baseboard, so the module onboard antenna has a larger clearance area compared to the bottom to reduce the impact of metal devices on PCB antenna and wireless signals. Or PCB is hollowed under the antenna.



## Updating description of historical versions

Revision	Release Data	Summary
V1.0	2017/03/10	First draft
V1.1	2017/08/15	Adding module layout description, firmware download description

Created by : Frank Wong

Date : 8/15/2017

## 7 Purchase and support

E-mail: sales@sz99iot.com  
[Frank@sz99iot.com](mailto:Frank@sz99iot.com)

Tel. 0755-88602663

Address: 609C north block, Cangsong Building, Tairan Seven Road, Futian District, Shenzhen

Website: [www.sz99iot.com](http://www.sz99iot.com)

\*RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

### § 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### § 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



---

## § 15.105 Information to the user.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.