

Smart Latch

User's Manual



Model # SL-SL-1

Smart Latch(SL-SL-1)


The SL-SL-1 is designed for new storage construction sites and also to support retrofit into existing storage facilities. The lock is designed for both outdoor and indoor and will work flawlessly under extreme environments. The SL-SL-1 operates on six (6) Energizer L92 AAA batteries , it will

continue to perform during power outages.

The Smart Latch is a battery powered device that contains a 2.4GHz 802.15.4 compliant radio that acts as a Zigbee end device in the SmartLok network. It wirelessly communicates with the Gateway or Repeaters on the network

Specifications


- 6 Energizer L92 AAA batteries
- Operational Temperature: -34C - 55C



How to Operate Smart Latch

1. Enter your four digit PIN number followed by the "SEND" button using the keypad.
2. The LED light will turn green and the lock will be unlocked.

If the LED did not turn green and the lock didn't unlock, please try again or see a manager.




Smart Latch Installation

1. Use the template provided to drill the holes in door. Please note, four of these holes will align with the standard holes on some door manufacturers.

2. Attach four screws in appropriate $\varnothing.321$ holes. Screws are provided with your Smart-Latch.

Dimensional drawing below provided in case of lost template.




How to Replace Batteries in Smart Latch

1. Place the lock into maintenance mode.
2. On the underside of the Smart Latch, unscrew the two (2) screws from the

battery door with a Phillips screwdriver.
3. Replace the batteries with six (6) AAA batteries.
4. Replace the battery door

and secure with the two (2) screws removed in step one.
5. Remove the lock from maintenance mode.



FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IC statement:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC Radiation Exposure Statement:

This equipment complies with Canada radiation exposure limits set forth for uncontrolled environments.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Déclaration d'IC sur l'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux radiations définies par le Canada pour des environnements non contrôlés. Cet émetteur ne doit pas être installé au même endroit ni utilisé avec une autre antenne ou un autre émetteur.

Smart Latch SL-SL-1

User's Manual

