


X100

USER MANUAL
READ BEFORE USING

1


PACKAGE CONTENTS

- X100 Wireless Earbuds
- On-The-Go Charging Case
- 6 × Silicone Eartips (2 are attached)
- 1 × Carrying Pouch
- 1 × Charging Cord
- Operation Manual



PRODUCT DIAGRAM

- ① Microphone Hole
- ② Multi-Function Button
- ③ Charging Contact
- ④ Micro USB Port (Input)
- ⑤ USB-A Port (Output)
- ⑥ LED Indicator



2

PRODUCT SPECIFICATIONS

Product Name	X100
Wireless Version	V5.0
Operation Range	≤10 Metres (Unobstructed Effective Range)
Earbud Charging Time	≤90 minutes
Charging Case Charging Time	≤150 minutes
Play Time	3 ~3.5 Hours (at 75% volume)
Talk Time	3 Hours (at 75% volume)
Standby Time	108 Hours
Wireless Profiles	A2DP, AVRCP, HFP, HSP
Earbud Battery Type	50mAh Rechargeable Lithium Batteries
Charging Case Battery Type	2600mAh Rechargeable Lithium Batteries

HOW TO CHARGE

Charging The Earbuds

1. When the earbuds is low on battery, the red indicator flashes 2 times every three minutes, prompting three times. At the same time, the voice prompts "low battery, please charge".
2. When the earbuds are charging, the blue light flashes. When the battery is fully charged, the light is off.

(When charging the earbuds, please refer to the following charging indicator light)

Battery Level	The Charging Case LED Indicator Light Status
0 ~ 33%	One blue light flashes once every 2 seconds
33 ~ 66%	Two blue lights flash twice every 2 seconds
66 ~ 99%	Three blue lights flash thrice every 2 seconds
100%	Blue light is off

3

Charging The Charging Case

1. When the charging case is low on battery, the indicates light will flash twice every 1 second, and the light will go out after 10 seconds.
2. When charging, the blue light of charging case is blinking. When it is fully charged, the blue light will illuminate.

Battery Level	The Charging Case LED Indicator Light Status
0 ~ 33%	The first blue light flashes once every 1 second
33 ~ 66%	The second blue light flashes once every 1 second
66 ~ 99%	The third blue light flashes once every 1 second
100%	Three blue lights keep light

HOW TO PAIR

First Time to Pair with Devices:

Note: Before first time using, please remove the isolation film on the earbuds and put the earbuds into the charger to fully charge; The right earbuds is main earbuds, TWS pairing is controlled by the main earbuds.

1. Open the chargeing case and pick up two earbuds, the earbuds will automatically turns on and enter the TWS pairing mode. (After connected: The right earbuds voice prompts "Enter pairing mode" and indicator light flashes red and blue light alternately; The left earbuds indicator is off)
2. Turn on the Bluetooth, search for earbuds pairing name "X100", and click to connect. (After connected: The right earbuds voice prompt "Pairing Successful" and earbud indicator lights off after 5 seconds.)

4

Second Time to Pair with Devices :

Take two earbuds out, the earbuds automatically enters the TWS pairing mode, then automatically connects to the last successfully paired mobile device. (TWS binaural pairing takes 4 seconds, Bluetooth earbuds and device connection takes 8 seconds)

- *The earbuds turn off automatically when you put them back to the charging case. (To manually power off, long press the earbuds buttons for 4 seconds)
- *The left and right earbuds can be used separately to make calls and play music.

HOW TO WEAR

- ① Select the earbuds of suitable size.
- ② Put earbuds into your ear canal.
- ③ To get the best sound, the top of the carrying pouch should fit tight into the ringe of the ear.

HOW TO RESET PAIRING

1. Turn the left and right earbuds on manually. (In the off state, press earbuds button for 2 seconds to turn on)
2. First double click on the left earbuds, then double click on the right earbuds. (Attention: it Should be quickly double click)

HOW TO CARE FOR YOUR EARBUDS

Always store the earbuds in the charging case to keep it safely. Avoid storage at extreme temperatures. (Above 45℃ / 113°F or below -0℃ / 32°F) Otherwise, it will shorten the battery life and affect the earbuds.

5

CONTROLS

Listening to Music

▶ Play Music	Press either earbud button for once.
⏸ Pause Music	Press either earbud button for once.
⏭ Next Songs	Press the right ear for two seconds
⏮ Previous Songs	Press the left ear for two seconds.
🗣 Activate/Stop Siri	Double press either earbud button.

Making and Answering Calls

☎ Answer call	Press either earbud button for once.
📞 End Call	Press either earbud button for once.
📞 Reject Call	Press the either earbuds for two secons.
📞 Hold Current Call, Answer Second Call	Press either earbud button for once.
📞 End Current Call, Answer First Call (Being Held)	Press either earbud button for once.
📞 Reject Second Call	Press the either earbuds for two seconds.
📞 Switch Calls	Press the either earbuds for two seconds.
📞 Switch Phone Chat Device	Press the either earbuds for two seconds.

6

FAQS

Questions	Answers
Q1: Can not find the earbuds Bluetooth "X100" on devices.	Need to restore factory defaults. (1) Take the two earbuds out, then close it. (2) In the off state, press earbuds button for 2 seconds to turn on. (3) First double click on the left earbuds, then double click on the right earbuds. (Attention: It should be quickly double click)
Q2: Can not pair earbuds with your devices.	(1) Pick up the earbud, it will power on automatically. (2) Remove All Bluetooths on your device's Bluetooth menu, Reboot the device's Bluetooth, search "X100" and tap to connect.
Q3: The earbuds fail to turn on.	(1) Peel off the plastic pieces from both earbuds. (2) Fully charge the charging case. Then take X100 from the case. (3) If still no work, hold still the earbuds buttons for 4 seconds to check if they work or not.
Q4: The right earbud can not connect with the left earbud.	Please try the following steps : (1) Please remove all Bluetooth devices from the Bluetooth menu. (2) Open the charging case and take out the Right earbud, then take out the Left earbud. (3) Double click quickly the left and right earbuds at the same time. (Attention: They should be double click in five seconds) (4) Confirm the binaural mode by observing the change of the indicator light. (After connected: The right earbud indicator light will flash alternately from blue to red; The left earbud indicator light will turn off)
Q5: The right earbud cuts out and in.	(1) Pair with other devices to check if this issue is caused by X100 earbuds. (2) Please remove all Bluetooth devices from the Bluetooth menu, then restart the phone and Connect again.
Q6: The left earbud is fully charged while left earbud is not full charged yet.	The left earbud is the master earbud, so left earbud will consume a little more electricity than right earbud.
Q7: Other issues?	No bother to return back, feel free to contact us at XXXXXX@XXX.com. We promise you with a satisfied solution.

7

CORRECT DISPOSAL OF THIS PRODUCT

(Waste Electrical & Electrical Equipment)
This symbol shown on the package or its literature indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human healthy from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

WARRANTY

X100 comes with an industry-leading 12 months warranty that begins from date of purchase.

The warranty applies to the X100 Bluetooth Earbuds and necessary parts. The warranty does not apply to damage resulting from failure to follow the instructions, accidents, abuse, alterations, or disassembly by unauthorized individuals.

ARE YOU 100% SATISFIED?

If you have questions or concern of our product, don't hesitate to contact us directly at: XXXXXX@XXX.com

X100 Earbuds has an award-wining warranty, exchange, and customer service program that guarantees hassle-free solutions to any issue you might have within 24 hours.

8

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part

15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.