









70*100mm

<p>Quick Installation Guide Please read the instructions carefully before use</p> <p>Download and install Scan the QR code below to download and install the "PixLinkCam" APP. iOS is available on Apple Store and Android is available on Google Play. Note: it is recommended to use the browser or a third-party scanning software to scan and download the APP. The scanning function of wechat does not support downloading apps directly.</p>  <p>PIX-LINK CAM</p>	<p>Add a device Click "+" to add the activated camera, or click the "+" button in the upper right corner of the App. The connection modes include direct connection to the Device AP, network distribution for the device AP, and Online Device Addition. Add 4G Device Select a connection mode.</p> 	<p>Tap Device AP Direct Connection to connect the device. Go to WiFi configuration and select the appropriate hotspotConnect (for example, "DGOF"). If the connection is successful, return to APP and the device is addedSuccess. (If the APP does not automatically add devices, click search to add devices.)</p> 	<p>Once the camera is online, click on the camera you just added to watch the live video. You can control the device in the video interface.</p> 	<p>Click  You can connect to WiFi. The network configuration is successful. Procedure (Note: Connection required 2.4G WiFi network)</p> 	<p>Click on the top right corner  icon to view multiple video screens at the same time.</p> 	<p>Product setting interface functions:</p> 	<p>Motion detection function: When the motion detection function is enabled, the device will be automatically displayed in front of the camera Take pictures when the dynamic picture is abnormal.</p> 	<p>FCC Statement</p> <p>Note:if the application always fails,try checking the following:</p> <p>A.The mobile phone is not connected to the AP of the camera, The configuration is to connect the mobile phone to the AP hotspot to the camera. B.Common routers are supported. Public routes that require login page authentication are not supported for the time being. C.Pay attention to the network name, network password and UID when configuring. D.Currently,Chinese WiFi name and password and special symbols are not supported. E.Wifi signal of 5G is not supported.</p> <p>Common Problem</p> <p>1.Why can't the APP search detect the camera/can't configure the network? A:Please confirm that the device is connected normally, and check whether the APP usage permission is restricted. 2.Why does the camera always ask for a username and password? A:The default password of the camera is admin. If you forget the user name or password, you can restore the camera to the factory settings to obtain the default user name and password. 3.How can I restore the camera to factory settings? A:Please press the reset button of the camera for about 5 seconds until the camera restarts.</p> 
---	--	---	---	---	---	--	---	---