


成品尺寸： 115X150MM
80克书写纸黑白印刷 风琴页折叠

VIVITAR®

wemakefun

Quick Start Guide

IPC 211 (5V1A)




Package contents


- 1x Indoor camera
- 1x AC charger
- 1x Power cable (built-in)
- 1x Quick start guide

* Note: Memory card not included

Description



- 1.) Light Sensor
- 2.) Lens
- 3.) Micro SD card
- 4.) Microphone




- 5.) Power cable
- 6.) Speaker
- 7.) Reset button

* Hold and press the reset button for 3 seconds to reset the connection and delete the device from the app.

Before using the camera

- 1.) Insert the memory card (not included) for normal use.



Note: Class 4 or higher micro SD (up to 32GB) memory card is required for normal use.
Please format the memory card before using.

- 2.) Before mounting the camera, use your smartphone to test if the Wi-Fi signal be covered and strong signal.
Place the camera in a location with a clear, unblock field of view.

Installation – Connect the camera with the app

1.) Power the camera

Use the supplied power adapter to connect the power cable of the camera, the camera will be started automatically.

2.) App setup and installation

Use your mobile phone or tablet to search for "Ulooka" in Google Play (for Android OS) or in the Apple app store (for iOS) to find the app, and install it according to the instructions.





OR



Ulooka

Open the APP, read the "Privacy Policy" and click "Agree".

APP pop-up prompt: For message push notification permissions, APP Bluetooth connection and positioning permissions, and to enable the Bluetooth function of your phone, please go to settings and confirm.



3. Click "Next" and enter the "Wi-Fi" account and password.
4. Please aim the doorbell lens at the QR code on your mobile phone and keep a distance of 10-15cm until you hear the beep and click "Hear the beep".

← Setup Device WIFI

Step 2.Select the network and input the password, then click on the button"Next".


WiFi Name

(If your router releases 2.4 and 5.0GHz dual Wi-Fi, please select 2.4GHz only.)


Password

Next

← Setup Device WIFI



Please aim the camera lens to scan the QR code, Keep a distance of 10-20cm, Until you hear a prompt tone or the slow flashing indicator light changed!



Hear a prompt tone !


The camera never responded!

5. The device is added successfully.
Tap the app to enter the live view.
(Note: If the connection is not successful, please check whether the Wi-Fi name and password are correct.
Only 2.4GHz wireless network is supported; or reset the device and reconnect according to the above steps.)


Mobile message push

When a new user opens the APP, the system will prompt "App notification permission is disabled".

Please set it according to the pop-up window, or go to the phone settings, application notification management, find Ulooka APP and turn on the allow notification permission. For details, please refer to APP [About] - [App push message - guidelines]



Interface description:



Icon	Instructions for use
	Return
	Bright adjustment
	Contrast adjustment
	Up and down
	Inverted light switch
HD	Image resolution
	Talk
	Video
	Photograph
	Monitor

Function introduction

1. Message push: When there is a motion, the mobile phone will receive a push message from the APP. Click on the push pop-up to enter the live view.

2. Camera sharing: The APP can share the camera with others. Open the APP-Settings-Sharing-QR Code. To be shared, you need to download the APP and scan the QR code.

3. Working indicator light:

Flashing blue light: Waiting for connection

Blue light is always on: The network is connected

Precautions

- Please remove the lens protective film when scanning the QR code to configure the network.
- Because different mobile phone models have different push settings, please set them according to your needs and model.
- Only supports 2.4G Wi-Fi, and does not currently support 5G or Wi-Fi with
- Chinese or special symbols.
- Since metal can easily interfere with WIFI signals, please try to avoid installing the device on a metal wall.

Q: Camera do not connect to my Wi-Fi network?

A: Make sure the camera indicator(near the reset button) is flashing. If the indicator light is not flashing, please press and hold "Reset Button" located at the back of the camera (see the Description section).

- Make sure the Wi-Fi network is a 2.4GHz network, device will not connect to a 5GHz network.
- Test your Wi-Fi network work with other devices such as your phone or computer to make sure it is operation properly.
- The Wi-Fi connection may be out of range during pairing. Use your phone to check range, it is recommended to have at least 2 signal bars showing for proper connection.
- Your Wi-Fi network password is case sensitive, make sure you are entering it correctly.

Q: The camera is o -line

A: -There may be a temporary issue with your internet connection (e.g., service disruption). Please try again in a few minutes.

- Make sure your Wi-Fi router is turned On.
- The camera may not have power source, make sure the wall switch and breaker is in the On position.
- Make sure the camera is getting a good signal from your Wi-Fi router. Use your phone to check range, it is recommended to have at least 2 signal bars showing for proper connection.

The camera may have been disconnected from your Wi-Fi network, press and hold Reset Button(see the Description section) until you hear an audible tone.

VIVITAR WARRANTY

This warranty covers the original consumer purchaser only and is not transferable. This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty:

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 or Visit our website at www.vivitar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures.

Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service.

It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE.

NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY.

NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Technical Support

For technical support issues please visit our website at www.vivitar.com.

You can find manuals, software and FAQ's on the website. Can't find what you are looking for? E-mail us at support@vivitar.com and one of our technical support team members will answer your questions.

For phont support in the US please call 1-800-592-9541.

SAKAR / VIVITAR INTERNATIONAL

195 Carter Drive
Edison, NJ 08817

