


Test Model: AKZ-M4

## Smart Socket Instruction Manual



## UNDERSTANDING INTELLIGENT SOCKETS

---



### FUNCTION KEYS AND INDICATOR LIGHTS

Keys: Short press the power switch button, bluelight on indicates it is working, bluelight off indicates it is not working.

Long press the power switch button for 5 seconds, bluelight flickers-enter configuration mode.

Indicator lights: The bluelight is in a slow flash state, indicating that the network connection is abnormal. Please check the router or network configuration.

Bluelight on indicates it is working, bluelight off indicates it is not working.

## TECHNICAL PARAMETER

---

Model: AKZ-M4  
Product size: 10A  
Maximum current: 10A  
Input voltage: AC 90~250V  
Output voltage: AC 90~250V  
Maximum load: 2200W 10A Working temperature: 0°C - 40°C  
Wireless type: Wi-Fi 2.4GHz Wireless standard: IEEE 802.11  
b/g/n  
Support system: Android\IOS

## HOW TO START

### ① DOWNLOAD SOFTWARE

Scan QR code download Smart Socket APP, register an account and login.



**②CONNECT THE PRODUCT TO THE POWER SUPPLY**


Long press the power switch button for 5 seconds, blue light flickers.



**③ADD DEVICE**

Confirm that the mobile phone is connected to the available WiFi network and click Add socket.

(Note: the WiFi network of the 5G band is not supported)



Make sure the device blue light is flashing fast.

#### ④NETWORK CONFIGURATION

Enter the WiFi router password for the current connection of your cell phone. Click confirm.




Wait for configuration to complete.



### ⑤CONFIGURATION COMPLETE

The blue light changed from flicker to light. Click "Done" to add the device successfully.



**Warning:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.  
NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

**RF Exposure Statement**

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 2.0 cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter