

Switch wireless controller using manual

Switch mode connection :

- 1) First time connect: turn one the switch console to connect to the Bluetooth interface. Press Home button on the controller for 5 seconds to enter Bluetooth search mode, LED1-LED4s flash quickly, after connect successfully, the corresponding led light remain on!
- 2) Second time connect: Press Home button on the controller for 3 seconds to enter Bluetooth search mode, LED1-LED4s flash quickly, after connect successfully, the corresponding led light remain on!

Note: When using the controller, the "Bluetooth function" and "pro wired function" of the switch console must be " on " (to use the controller normally)

PC Mode connection:

- 1) Connect the controller to the PC with the USB cable, XINPUT will be the default mode; LED2 is remain on!
- 2) From Xinput mode Long press 'O(screenshot)" button for 2s can change to D input mode, LED 3 solid on.

Led light Charge:

- 1) Controller off: 4 LEDs lights flash slowly when charging, fully charged will off!
- 2) Connecting to console: 4 LEDs lights flash slowly when charging, fully charged will off!

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.