






Outdoor CPE



Quick Installation Guide



WEB Configuration


1. PC configuration if PC connect CPE by wireless

Connect to CPE's wireless SSID: Wireless 2.4G_XXXXXX/Wireless 5.8G/Wireless 5.8G_XXXXXX, wireless key: 66666666, Set PC wireless network IP to 192.168.188.x(x: 11-200), same network segment as CPE, subnet mask: 255.255.255.0




2. PC configuration if PC connect CPE wired

If connect PC and CPE wired, Set PC local network IP to 192.168.188.x(x: 11-200), same network segment as CPE, subnet mask: 255.255.255.0





Check the local network connection




Set Static IP address for PC

3. Login Web Configuration

Use IE browser to access <http://192.168.188.253>, pop up the login page shown below, input the login password: admin, enter into the home page.




Setup Wizard



Using Setup Wizard the CPE device can be set up to Repeater and AP mode.

- Repeat mode**
Bridge the exist wireless signal then transmit Wi-Fi for more range.
- AP mode**
In this mode, NAT, DHCP, firewall, and all WAN-related functions are turned off. All wireless and wired interfaces are bridged together, regardless of LAN and WAN.
- Configuration method**
According to the quickly setup wizard of each mode shown in the above figure, set the parameters and options based on user needs, click next until the setting of each step is completed.


4. Configure Wireless



- Use a laptop or mobile phone to test the wireless network Internet, click on the wireless network, select the wireless SSID, input the password to test whether PC or mobile phone can be online.
- Check the wireless network connection status, signal strength and speed, transmission and data, click network connection details to see if the IP address and DNS server address are correctly obtained, confirm device is working properly.

5. Login WEB by Mobile Phone

Outdoor CPE supports mobile phone Login and set, the configure page showed as follow:



- Mobile phone connect with outdoor CPE, SSID: 5.8G/Wireless 5.8G_XXXXXX, wireless key: 66666666
- Configure static IP:
 - Android Mobile Phone:** Open settings in phone, turn on WLAN and find the SSID of the CPE, access to wireless network settings then choose "static IP" in the menu, set the mobile phone IP address as 192.168.188.x (x: 11~200) same network segment as CPE, subnet mask: 255.255.255.0, then gateway, subnet mask and domain.
 - iOS Mobile Phone:** Open settings and choose wi-fi connect with CPE, click exclamation mark (!), manual set IP address 192.168.188.x (x: 11~200) same network segment as CPE, subnet mask: 255.255.255.0, then gateway, subnet mask and domain.
- Input 192.168.188.253 on the internet explorer bar, input admin to login the mobile configuration page.
- Login password: admin

Channel Table

Wireless Bridge Regional Channel Code Instructions

Regional Code	5G Channel	
ETSI	5.50GHz	(Channel 100)
	5.52GHz	(Channel 104)
	5.54GHz	(Channel 108)
	5.56GHz	(Channel 112)
	5.58GHz	(Channel 116)
	5.60GHz	(Channel 120)
	5.62GHz	(Channel 124)
	5.64GHz	(Channel 128)
	5.66GHz	(Channel 132)
	5.68GHz	(Channel 136)
	5.70GHz	(Channel 140)


(Note: for the frequencies above indicated the DFS function must be activated)

Trouble shooting

Trouble	Reason	Solution
Packet Latency	1. Wireless Interference 2. Distance is too long, or there are some bar between them 3. CPE's angle in wrong direction, weak signal	1. Use Wi-Fi analysis to choose the best channel, or change to 5G CPE 2. Distance be in normal distance, and avoid bar 3. Adj set the angle of CPE according to signal strength
Wrong password	1. Forget password 2. Input wrong password 3. Too much cookie	1. Press reset button in 10 seconds to reset device, the default password is admin 2. Re-input the password 3. Clear cookie, run arp -d to clear MAC table
Can not login WEB	1. Local IP is not in the same network segment of CPE 2. LAN connection by other devices 3. LAN Connection or Ethernet cable has problem 4. Too much cookie, MAC address haven't update	1. Png 192.168.188.253 to see connection status 2. Stop other devices or change to another IP 3. Check LAN Connection and Ethernet Cable 4. Clear cookie, run arp -d to clear MAC address
System LED light off	1. PoE power supply is not working 2. Some problem in CPE's PoE port 3. Ethernet cable is loose, RJ45 port is wrong 4. Check if voltage is normal, if socket has problem, if input voltage of PoE adapter is normal	1. Check if PoE Adapter or PoE switch work 2. Check if PoE port of CPE is OK 3. Check if Ethernet cable is loose, if Ethernet port is not working 4. Check if voltage is normal, if socket has problem, if input voltage of PoE adapter is normal
Low transmission Rate	1. Packet Latency 2. Ethernet cable circuit 3. Network virus attack 4. Too much access users	1. Adjust the distance, angle and channel to decrease latency 2. Check the connection of the network cable 3. Check port isolation to avoid network virus and broadcast storm 4. Decrease the access users
Device always Dead	1. Static electricity 2. Running it too long 3. Lightning stroke	1. Make CPE or PoE adapter need ground connection 2. Reboot CPE device 3. After lightning, device POE port broken or unstable, better to deploy lightning conductor



①. Android system setup steps



②. iOS system setup steps

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.