


SMC-MIXER

User Manual



CubeSuite for Android/iOS: scan the QR code

I . PACKING LIST

EN

- SMC-Mixer Midi Controller
- USB-C connection Cable
- User Manual

II. CONNECTION

EN

■ **USB Connection:** Plug the cable through the USB port to the Windows/Mac it will automatic be recognized, When plug into Windows/Mac, SMC-Mixer will be charging at the same time;
(Red light: charging, Green light: charging complete)


■ **Wireless Connection:** Press and hold the BT button to turn on/off wireless function, when the light flashing the wireless function is activated, when the light stay on device was connected successfully;

■ **Wireless Adapter:** Plug Wireless Adapter B into Windows/Mac, connection was successfully when both lights stay on;

■ **Direct Wireless:** Activated BT function of Windows/Mac/ios/Android, Select SMC-Mixer on the list (Windows users need BT 5.0 and extra BLE Midi Driver);

■ **Low battery notification:** When the battery level is low, the shift button will flash to indicate it is time to charge.

Note: Wireless Adapter A and B are not within the package need to buy additionally;





Mac: Connect directly via BT inside MIDI Studio Setup



Windows: You need to download a driver, scan the QR code in the back of device



Android: You need the software that supports Ble MIDI, such as FL studio. Search for a MiDI keyboard in your MIDI device and connect it

■ Ableton Live:

Open the preferences menu in Ableton Live, set the Control Surface to "MackieControl", and select "SMC-Mixer" for both input and output.

■ FL studio:

Access the MIDI settings in FL Studio, enable "SMC-Mixer", set the Controller Type to "Mackie Control Universal", and ensure SMC-Mixer input and output are on the same port.

■ Cubase:

In Cubase, navigate to Studio Setup, add the "Mackie Control" device, and choose "SMC-Mixer" for both MIDI input and output.

■ Logic Pro:

In Logic Pro, go to Control Surfaces > New > Install, add "Mackie Control", and set both the Output Port and Input Port to "SMC-Mixer".

■ Studio One:

In Studio One, visit Options > External Devices, add "Mackie Control", and set both "Receive From" and "Send to" to "SMC-Mixer".

■ BitWig:

In BitWig's Settings > Controllers, add the "Mackie Control" controller, and designate "SMC-Mixer" for both MIDI input and output.

■ Reaper:


In Reaper, navigate to Preferences > Control/OSC/web, add "Mackie Control Universal", and select "SMC-Mixer" for both MIDI input and output.

■ CakeWalk:

In CakeWalk, enter Preferences > Control Surfaces, incorporate "Mackie Control", and choose "SMC-Mixer" for both input and output.

IV. MODE SELECTION

EN



Mode selection :

Hold down the shift button and toggle between the left and right buttons to switch between DAW mode and User mode ;


V. KNOBS

EN



Knobs:

Manipulate the pan settings individually for tracks one through eight (Use Channel left & Channel Right Button to Switch Tracks) .

**LED Indicator:**

The LED will flash when the position of the faders doesn't align with the track volume.

Fader:

Manipulate the volume levels individually for tracks one through eight (Use Channel left & Channel Right Button to Switch Tracks) .

Track control buttons:

Each group of four track buttons controls the mute, solo, record, and select functions for their respective track.



Globe control buttons :

These buttons respectively control play, stop, record, rewind, fast forward, switching to the previous 8-track group, switching to the next 8-track group, and directional navigation (up, down, left, right).

(The knobs, faders, track control buttons, and global control buttons can be configured using software on PC, Mac, iOS, and Android. Scan the QR code located on the back of the product to download software.)

VIII. TECHNOLOGY PARAMETERS

Product Dimensions	256mm (L) x 122mm (W) x 40mm (H)
Product Weight	445g
Faders	Eight groups of fader to control track volume;
Buttons	43 assignable control buttons;
Knobs	8 assignable endless 360 degree encoders;
Output	USB-C port; Wireless connection with Windows/Mac/ios/Android; Wireless Midi Out Function (Extra wireless midi device needed for wireless Midi Out)
Power	Battery supplied or USB-bus-powered
Battery Model/Type	603040
Battery Nominal Voltage	3.7V
Battery capacity	780mAh

★ Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement


The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

SMC-MIXER

用户指南



手机端Android/iOS下载APP: 扫描二维码下载

一. 包装清单

CN

- SMC-Mixer MIDI控制器;
- USB连接线;
- 用户指南;

二、设备连接

CN

■ **USB 连接:** 通过 USB 端口将线缆插入 Windows/Mac, 系统会自动识别。当插入 Windows/Mac 时, SMC-Mixer 会同时充电; (红灯: 充电中, 绿灯: 充电完成)


■ **无线连接:** 长按 BT 按钮以开启/关闭无线功能, 当灯闪烁时, 无线功能已激活, 当灯常亮时, 设备已成功连接;

■ **无线适配器:** 将无线适配器 B 插入 Windows/Mac, 当两个设备的无线指示灯都常亮时, 连接成功;

■ **无线直连:** 激活 Windows/Mac/ios/Android 的 BT 功能, 在列表中选择 SMC-Mixer (Windows 需支持 BT 5.0 及额外的 BLE Midi 驱动程序);

■ **低电量提示:** 当电池电量较低时, shift 按钮会闪烁, 表示需要充电。

注: 包装内不包括无线适配器 A 和 B, 需要另外购买;





Mac : 通过音频MIDI工作室进行无线连接;



Windows: 与Windows连接需要安装Ble Midi驱动，请扫描设备背面二维码下载



Android: 需要软件支持Ble MIDI（例如FI Studio Mobile），在软件MIDI设备中搜索并连接设备

■ Ableton Live:

在 Ableton Live 中打开偏好设置菜单，将控制面板设置为 "MackieControl"，并将输入和输出都选择 "SMC-Mixer"。

■ FL studio:

在 FL Studio 中，进入 MIDI 设置，启用 "SMC-Mixer"，将控制器类型设置为 "Mackie Control Universal"，并确保 SMC-Mixer 的输入和输出使用相同的端口。

■ Cubase:

在 Cubase 中，进入 Studio 设置，添加 "Mackie Control" 设备，并将 MIDI 输入和输出都选择 "SMC-Mixer"。

■ Logic Pro:

在 Logic Pro 中，前往 控制面板 > 新建 > 安装，添加 "Mackie Control"，并将输出端口和输入端口都设置为 "SMC-Mixer"。

■ Studio One:

在 Studio One 中，访问 选项 > 外部设备，添加 "Mackie Control"，并将 "接收自" 和 "发送至" 都设置为 "SMC-Mixer"。

■ BitWig:


在 BitWig 的设置 > 控制器 中，添加 "Mackie Control" 控制器，并将 MIDI 输入和输出都指定 "SMC-Mixer"。

■ Reaper:

在 Reaper 中，进入 偏好设置 > 控制/OSC/网络，添加 "Mackie Control Universal"，并将 MIDI 输入和输出都选择 "SMC-Mixer"。

■ CakeWalk:

在 CakeWalk 中，进入 偏好设置 > 控制面板，加入 "Mackie Control"，并将输入和输出都选择 "SMC-Mixer"。




模式选择:

按住 shift 按钮并使用左, 右按钮进行切换, 以在 DAW 模式和用户模式之间进行切换。



旋钮:

调整一至八轨道的声像设置 (可通过全局控制按钮轨道左, 右按钮切换轨道)



LED指示灯:

当滑动推杆的位置与轨道音量不一致时，LED会闪烁。

推钮:

调整一至八轨道的音量（可通过全局控制按钮轨道左，右按键切换轨道）

轨道控制按键:

每组四个按键分别控制各自轨道的静音，独奏，录音和选择功能。



全局控制按键：

这些按键分别控制播放，停止，录音，倒带，快进，切换到前一个8组轨道，切换到下一个8组轨道和方向导航（上，下，左，右）。

（旋钮、推钮、轨道控制按键和全局控制按键都可以通过PC、Mac、iOS和Android的软件进行配置,请扫描产品背面的二维码下载软件。）

八、技术参数

产品尺寸	256mm (L) x 122mm (W) x 40mm (H)
产品重量	445g
推钮	8个可分配的推钮;
按键	43个可分配的控制按键;
旋钮	8个可分配的无级360度编码器;
输出	USB-C端口; 无线连接Windows/Mac/ios/Android; 无线Midi输出功能 (无线Midi输出功能需要额外的无线midi设备)
电源	电池供电或USB总线供电
电池型号规格	603040
电池标称电压	3.7V
电池额定容量	780mAh