

LOC8 FINDER TAG- USER MANUAL (UNIVERSAL)

APPLE PAGES

GOOGLE PAGES

COMPLIANCE STATEMENTS

SIDE 1

FRONT PAGE









INTERNAL PAGE 1

INTERNAL PAGE 2

INTERNAL PAGE 3

INTERNAL PAGE 4

INTERNAL PAGE 5



SIDE 2

CHECKING BATTERY LEVEL

When LOC8 Finder Tag Universal's battery level is low, you will receive a reminder notification on your phone, via the Find My app. You can also check the battery level of the LOC8 Finder Tag Universal in the Find My app.

USE LOST MODE (FOR APPLE)

1. If you can't find your wallet, open the Find My app on your iPhone.
2. Click the 'Items' icon at the bottom of your screen.
3. Tap on your LOC8 Finder Tag icon displayed on your screen.
4. Scroll down to "Enable Lost Mode".
5. Tap "Continue".
6. Enter your required contact details to finalise "Lost Mode".

\*Your LOC8 Finder Tag will stay linked to your Apple ID, unless you unpair it.  
\*If someone finds your item while it is in Lost Mode, they can use their iPhone or any NFC-capable device to reach you.

TROUBLESHOOTING (FOR APPLE)

This device can be reset if you have trouble pairing the wallet with your iPhone, or if you want to unpair it and give it to someone else.

To reset:

1. Hold down the tracker button for 10 seconds.
2. Release the button once you hear the ringtone sound five times.
3. You can repeat this step in "SETUP WITH APPLE'S FIND MY APP" to pair the wallet with your iPhone.

RE-ENABLE MODE (FOR GOOGLE)

Once the device is removed from the app, it will exit pairing mode. To pair again, restart the device or perform a factory reset. This will activate pairing mode, enabling you to reconnect with the app.

TROUBLESHOOTING (FOR GOOGLE)

With the device powered on, double-click the button to hear a beep. Then, press and hold the button for 8 seconds until the device beeps and the indicator light flashes three times. Release the button to complete the factory reset. The device is now ready to pair with the "Find My" app. Note: The reset only affects the "Find My" function. (After 2 seconds, you'll hear a "ticking" sound and see the light flash. Keep holding until the device beeps and the light flashes, then release the button.)

WARNINGS

Avoid exposing it to extreme conditions that may affect its functionality.

Keep LOC8 Finder Tag Universal away from all heat and fire sources, including heating equipment, heaters, ovens, open flames, and direct sunlight.

Do not attempt to repair or disassemble the LOC8 Finder Tag Universal equipment by yourself. Any unauthorized modification may result in damage or malfunction.

Avoid using or storing LOC8 Finder Tag Universal in environments with high humidity or temperatures exceeding 60°C (140°C) to prevent potential failures.

Responsibly dispose of LOC8 Finder Tag Universal products following the local government's regulations on waste disposal to minimize environmental impact.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements.

Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

GOOGLE DISCLAIMER

Find My Device network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ on select devices (tablets, phones, and laptops) and in certain countries for age-eligible users.

AUSTRALIAN WARRANTY

Warranty Period

12 Months

Warranty Terms

ALOGIC Corporation Pty Ltd warrants this product to be free from defects in materials and workmanship for the warranty period stated above from the date of purchase, provided the product is used in accordance with the accompanying recommendations and instructions.

Exclusions

This warranty no longer applies where any defect results from alteration, accident, misuse, abuse or neglect of the product.

How to Make a Claim

Please retain your receipt as proof of purchase and return the product with the receipt to your place of purchase to make a warranty claim. This warranty is in addition to your rights under the Australian Consumer Law.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights under New Zealand legislation.

ALOGIC Corporation Pty Ltd  
Level 14, 140 William St Melbourne VIC Australia 3000

INTERNAL PAGE 6

INTERNAL PAGE 7

INTERNAL PAGE 8

WARNINGS

AU COMPLIANCE