



T55

# Quick Start Guide

# CONTENTS

|  |    |
|--|----|
| USER INTERACTIONS AND RESPONSIBILITIES .....       | 3  |
| UNDERSTANDING YOUR PHONE .....                     | 5  |
| INSERTING THE SIM CARD .....                       | 6  |
| CHARGING THE DEVICE .....                          | 7  |
| USING THE HANDSET KEYS .....                       | 8  |
| ON SCREEN BUTTONS .....                            | 8  |
| BASIC PHONE FEATURES .....                         | 9  |
| SIGNING IN WITH YOUR GOOGLE ACCOUNT .....          | 9  |
| CALLING .....                                      | 9  |
| MAKING AND RECEIVING CALLS .....                   | 9  |
| WHEN YOU RECEIVE A CALL: .....                     | 11 |
| CONTACTS .....                                     | 12 |
| MANAGING YOUR CONTACTS .....                       | 12 |
| MESSAGING .....                                    | 12 |
| MULTIMEDIA .....                                   | 13 |
| CAMERA .....                                       | 13 |
| SAR INFORMATION .....                              | 15 |
| SAR COMPLIANCE .....                               | 15 |
| SAR RECOMMENDATIONS .....                          | 15 |
| METRO® BY T-MOBILE INFORMATION .....               | 16 |
| SERVICE .....                                      | 16 |
| ACCOUNT DETAIL: .....                              | 17 |
| PAYMENT OPTIONS: .....                             | 17 |
| MYMETRO® .....                                     | 18 |
| FOR ASSISTANCE: .....                              | 18 |
| PLEASE FOLLOW US AT: .....                         | 19 |
| METRO TERMS AND CONDITIONS OF SERVICE .....        | 20 |
| BILLING FOR PREMIUM AND THIRD-PARTY SERVICES ..... | 22 |

|                                  |    |
|----------------------------------|----|
| WI-FI CALLING .....              | 22 |
| FCC CAUTION: .....               | 24 |
| SAFETY PRECAUTIONS .....         | 26 |
| TAKING CARE OF YOUR DEVICE ..... | 28 |
| DEVICE RECOMMENDATIONS .....     | 28 |
| TEMPERATURE AND HUMIDITY .....   | 29 |
| RECYCLE YOUR PHONE .....         | 29 |
| DISCLAIMERS .....                | 30 |
| COPYRIGHT .....                  | 31 |



<http://www.sartick.com/>

The SAR-Tick label confirms that your mobile phone complies with international exposure standards

# User Interactions and Responsibilities


(IEEE 1725, Section 9.2)

- a) Do not disassemble or open, crush, bend or deform, puncture or shred.
- b) Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- c) Only use the battery for the system for which it is specified.
- d) Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- e) Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- f) Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard. Only authorized service providers shall replace battery. (If the battery is non-user replaceable).
- g) Promptly dispose of used batteries in accordance with local regulations.
- h) Battery usage by children should be supervised.

- i) Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- j) Improper battery use may result in a fire, explosion or other hazard.

For those host devices that utilize a USB port as a charging source, the host device's user manual shall include a statement that the phone shall only be connected to CTIA certified adapters, products that bear the USB-IF logo or products that have completed the USB-IF compliance program.

# Understanding Your Phone



|   |                                     |        |                       |
|---|-------------------------------------|--------|-----------------------|
| 1 | USB Jack<br>(Type-C)                | 8      | Volume Up/Down        |
| 2 | LED Front<br>Flash                  | 9      | Power On/Off          |
| 3 | Display                             | 10     | 3.5mm Headset<br>Jack |
| 4 | Microphone                          | 1<br>1 | Fingerprint<br>Sensor |
| 5 | Noise<br>Cancellation<br>Microphone | 12     | Rear Camera           |
| 6 | Internal Ear                        | 13     | LED Flash             |


|   |              |    |                                       |
|---|--------------|----|---------------------------------------|
|   | Speaker      |    |                                       |
| 7 | Front Camera | 14 | External<br>Speaker<br>(Speakerphone) |

## Inserting the SIM Card

1. Turn off your phone and remove the back cover and battery as shown.



2. Place the SIM card and micro SD card (if available) in the slot(s), as shown.



3. Replace the battery, then the back

cover of the phone.

---

① Please keep the SIM card out of the reach of children.

---

## Charging the Device

Before first use, it is recommended that the device is fully charged. To charge the device, use the travel adapter and USB-C data cable included in box with the handset. Alternately, you can also charge by connecting the device to a PC/Laptop via the USB-C data cable. Maximum charging time for the device is approximately 3 hours.



|  |   |
|--|---|
|  | <p>The device can be charged with the travel adapter/USB-C data cable or connecting the device to PC via the USB-C data cable</p> |
|--|---|

# Using the Handset Keys

---

## Using the Handset Keys

## Functions

---

- Long press the Power On/Off key to turn the phone on or off.
- Press once quickly to wake the screen or to turn off the screen.
- Long press to view quick options to Power Off/ Restart/ Screenshot/ Emergency.



- Adjust the volume using the Volume keys.

## On Screen Buttons

| Keys  | Functions                                  |
|---|--|
|  | Opens the most recently used applications. |
|  | Short tap opens the Home                   |

|   |   |
|---|---|
|   | Screen.<br>Long tap to open Google Assistant. |
|  | Back key or opens the previous screen.        |

## Basic Phone Features

### Signing in with your Google Account

Your Google Account lets you take full advantage of applications and services offered by Google Android market. Create or sign into your Google account to access Gmail, Google Play Store, Google maps and more.



Internet connection is required for setting up Google account.

To sign in to your Google Account, go to  
 →  → Accounts → Add account → Google.  
 Follow the registration steps to successfully configure your Google mail.

## Calling

### Making and Receiving Calls

- Open the Dialer application  icon.
- Enter the desired number from the  keyboard  icon directly and touch  icon to place the call or select a contact from Favorites  icon or




Contacts icon by touching these tabs, then choose the contact and tap to place the call.


- You can also use the Recent Calls tab to place a call by choosing from the list.
- To end the call, tap the icon.

When you receive a call:

- Incoming call: When your phone gets an incoming call, you can answer a call or decline a call.



- Received call: Tap  icon to disconnect received call.




## Contacts

- Swipe up from the bottom of the screen to open the App Tray.
- Tap the contacts  icon.
- Tap  icon to create a new contact and press the "Save" button to add a new contact.

## Managing Your Contacts

- Scroll up or down to find a contact or tap the search  icon and enter the first few letters of the name to find the contact.
- Mark contact as a favourite in your phonebook, tap  icon to add your contact in the favourite list.



## Messaging

To compose, send or receive messages slide your finger up on the home screen to open the app tray. Tap  icon to access


messaging.

- Tap  to compose a message. To start a conversation, enter name or phone number in the search bar.
- Tap  type in the recipient's number or select contact(s) from the contact list.
- Tap  to send the message.

## Multimedia

### Camera

Tap  icon to capture your memorable moments.




- Tap  icon to open the camera.
- The camera will detect and autofocus the selected object.



- To re-focus another object just tap on that object you want to focus.



- Capture the moment simply tap  icon.



# SAR Information

## SAR Compliance

- Your device is designed not to exceed the limits of emission of radio waves recommended by international guidelines.
- SAR (Specific Absorption Rate) is the measurement of body-absorbed RF quantity when the device is in use. SAR value is ascertained according to the highest RF level generated during laboratory tests.
- The SAR value of the device may depend on factors such as proximity to the network tower or use of accessories.
- The SAR value of the device at the head and body are 1.10W/kg and 1.40W/kg averaged over 1 gm of human tissue.
- The SAR limit for mobile devices is 1.6 W/kg.

## SAR Recommendations

- Use a wireless hands-free system (headphone, headset) with a low power Bluetooth emitter.
- Keep your calls short and use SMS whenever more convenient. This advice applies especially to children, adolescents and pregnant women.
- Prefer to use your handset when the signal quality is good.
- People having active medical implants should preferably keep the handset at least 15 cm away from the implant.
- Maintain a preferable distance of 15 mm from the device.

# Metro® by T-Mobile

## Information

### Service

You will need the following information when activating service:

- Your name, address and an eight-digit number that you will use to access your account (your personal identification number "PIN").
- Your serial number (IMEI) and SIM card number. If your phone has a removable battery, to locate the serial number, remove the phone from the box and remove the battery cover from the phone. The serial number is located near the bar code. It will be 14 to 18 digits. If your phone does not have a removable battery, check the box label or phone settings to locate the serial number. The SIM card number can be located below the bottom bar code on the back of the SIM card holder.
- Your choice of Metro plan and services including unlimited data, talk and text plans.
- Install the battery, if applicable, and SIM card in your new phone by following the step by step instructions in this phone's User Guide.
- Once your phone is powered up, dial 1.888.8metro8 (1.888.863.8768) to connect with an activation representative who will assist you in activating your phone. You can also activate your phone

online by visiting [metrobyt-mobile.com](http://metrobyt-mobile.com). (As soon as your service is activated, be sure to fully charge the phone's battery before using it again.)

Don't hesitate to ask your Metro representative for more information on additional features and services or visit [metrobyt-mobile.com](http://metrobyt-mobile.com).

#### Account Detail:

- Text Message Reminder. Metro provides a text message reminder on your phone before payment is due.
- E-statement. View your statement summary online. (Only available in select states.)
- Call Detail. View your call detail online for a listing of all local calls made during the service cycle. (Additional charge applies.)

#### Payment Options:

There are several ways to pay for your Metro service.

- AutoPay. Your credit or debit card is automatically debited two days before payment is due.
- Express Pay.

Pay by credit or debit card online at [metrobyt-mobile.com](http://metrobyt-mobile.com).

- By Mail. Include your account number and phone number on your check or money order and mail to Metro by T-Mobile, P.O. Box 5119, Carol Stream, IL 60197-5119.

- By Phone via Automated System. Pay by credit or debit card from your Metro phone by dialing 1.888.8metro8. (Convenience fee applies.)
- Store Payment Machine.\* Accepts cash, debit or credit card (with PIN). (Convenience fee applies.)
- Over the Counter.\* Pay at an Authorized Payment Location with cash, credit or debit card.
- eWallet.

Sign up for MyAccount through metrobyt-mobile.com and create your own secure eWallet where you can safely store cards for quick payment and set up autopay.

- Text to Pay. The secure and easy way to pay your monthly Metro service. Register your credit or debit card with the Metro eWallet service and simply respond to a text from PAYNOW (729699) to pay.

\* Not available at all locations.

#### MyMetro®

- Manage your Metro account right on your phone.

By dialing any of the customer service numbers you can change your rate plan, change your features and pay for service. Just follow the instructions on your phone.

#### For Assistance:

Please visit your local Metro store or refer to the following options if you need additional assistance.

- Sign up for MyAccount to view account

details, check your balance, make a payment, manage eWallet and more.

- Metro automated customer service from any phone 1.888.8metro8 and follow the prompts (1.888.863.8768)
- Online information [metrobyt-mobile.com](http://metrobyt-mobile.com)

Please follow us at:

 @metrobytmobile

 [facebook.com/Metrobytmobile](https://facebook.com/Metrobytmobile)

Copyright: Metro, MetroPCS and other words, slogans, designs and devices are registered or unregistered trademarks of T-Mobile USA, Inc. Copyright © 2019 T-Mobile USA, Inc. All other trademarks and other intellectual property are the properties of their respective owners.

Your device may not work if you alter its original software. This device will only operate with firmware versions that have been approved for use by Metro and the device manufacturer. If unauthorized firmware is placed on the device, it will not function.

Hearing aid compatibility: This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use

with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

Your phone's GPS system is enabled by default in order to permit the use of planned future services; see your phone's manual for instructions should you wish to disable your GPS for non-911 purposes.

## Metro Terms and Conditions of Service

For the most recent and up-to-date version of the Metro Terms and Conditions of Service to which you agree and will be bound when you activate, use, change or pay for your Metro service, please visit [metrobyt-mobile.com/terms](https://www.metrobyt-mobile.com/terms).

Welcome to Metro. We are pleased that you have selected us as your wireless carrier. Our Terms and Conditions of Service are available at <https://www.metrobyt-mobile.com/terms-conditions/terms-conditions-service.html>. These Terms and Conditions of Service apply to all devices and wireless services provided by us to you and consist of several parts, which may be amended from time to time.

In the event that the terms and conditions relating to a feature you may have selected or may be included in your Rate

Plan conflict with the Metro Terms and Conditions of Service, the Metro Terms and Conditions of Service shall control.

By: (a) giving us a written or electronic signature or telling us orally that you accept the Metro Terms and Conditions of Service; (b) activating Service (if you are a new subscriber); (c) using your Service after your Service is activated or after you make a change or addition to your Service; (d) paying for the Service; or (e) failing to activate Service within 30 days after the purchase of your wireless device, unless you return your wireless device within Metro's applicable return period, you agree to the Metro Terms and Conditions of Service and the terms and conditions of service and use related to any feature you may have selected or may be included in your Rate Plan, including, but not limited to:

- You waive your right to a jury trial in disputes with Metro;
- Your disputes with Metro will be decided by an arbitrator;
- You waive your right to institute or participate in class action litigation against Metro;
- You will provide Metro with accurate information about yourself;
- Metro may communicate with you from time to time about your Service;
- You will pay all taxes and regulatory fees even if your rate plan is inclusive of taxes and regulatory fees; and

- Metro may terminate your Service if you fail to timely pay for your Service or violate the Terms and Conditions of Service in any way, including abuse of the Service or violations of applicable laws.

Customer Service. If you have any questions regarding your Service or information in this Agreement, you may call our activation center at 1-888-8metro8 (1.888.863.8768).

## Billing for Premium and Third-Party Services

### California Residents Only

Certain parties besides Metro have the ability to place charges on your bill for premium services. You may access these services and authorize the placement of charges on your bill through your phone or online account. Metro also provides customers, at no additional cost, with the ability to restrict the placement of charges for premium and third-party services on your account. Contact customer care or go to

[www.metrobyt-mobile.com/blocking](http://www.metrobyt-mobile.com/blocking) for more information.

## Wi-Fi Calling

Wi-Fi Calling allows you to make and receive phone calls and messages over a Wi-Fi connection.

Important! You must have an E911 address registered with your account in order to use Wi-Fi Calling. You can register an E911 address via the myMetro® Android™ app that is either preinstalled on your phone, or

available for download from the Google Play™ Store. If you do not have an Android smartphone, you can call 611 to update the address.

## FCC Caution:

### a. § 15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### b. § 15.21 Changes or modification warning.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### c. §15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference

to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# Safety Precautions



Switch off your device in any area with potential explosive atmosphere such as refueling stations, fuel depots, chemical plants or places where blasting operation is in progress. Sparks arising out of radio frequency may cause fire or explosion. Remember to comply with legal requirements and local restrictions when using the phone. Use cell-phone when the signal quality is good. Your Phone's radio waves may interfere with medical devices.



Preferably maintain a distance of 15.3 cm (6 inches) between a wireless device and implanted medical devices such as pacemaker or cardioverter defibrillator. Switch off your device when regulations require you to do so. Always keep the phone and accessories out of reach of small children. Small parts such as the SIM card can be dismantled and swallowed by small children. Keep your calls short or send a text message (SMS) instead. This advice applies especially to children, adolescents and pregnant women.



Do not place the phone near electromagnetic data carriers such as Credit/Debit cards. Information stored on them could be lost.



Permanent damage to hearing may occur if you use earphones at high volume for prolonged periods. Set your volume to a safe level.



The mains voltage (V) specified on the power supply unit must not be exceeded to prevent damage to the charging device. The power supply must be plugged into an easily accessible AC power socket when charging the device.



Do not open the device under any circumstance. All other changes to this device are strictly prohibited and will invalidate the warranty.



The phone may cause interference in the vicinity of TV sets, radios and PCs.



Do not use the phone while driving. If absolutely necessary, use a wireless hands-free system (headphone, headset) with a low power Bluetooth emitter. Please put the phone safely in the phone stand. Do not put it onto any spot from which it may fall down during collision or emergency braking.



Flight is influenced by interference caused by the phone. It is not advised to switch on a phone during flight.



Please repair the device at a Micromax authorized service center only. Repairing the device by yourself invalidates the warranty rules.

## Taking Care of your device

Your device is a product of superior design and craftsmanship and should be handled with care in the following ways:

- Keep the device dry. Precipitation, humidity, and all types of liquids can rust the electronic circuits. If your device gets wet, wipe it with a dry cloth and take it to an authorized service center.
- Do not store the device in high or cold temperature. Extreme temperatures can shorten the life of electronic devices and damage batteries.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can get damaged.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, shake or bend the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device. Do not store or bring your device near magnetic fields for extended period of time.

### Device Recommendations

- Please put the device in a cool and well-ventilated place out of direct sunlight. We recommend you to charge the device at room temperature range.
- After a full charge, if the power reserve of the device tends to deplete

inordinately faster than usual, the battery life is at an end.

- Use only Micromax chargers and cables. Micromax will not be held responsible for user's safety when using incompatible accessories or supplies.

## Temperature and Humidity

- The device is designed for use within a temperature range of  $-10^{\circ}\text{C} \pm 5$  to  $55^{\circ}\text{C} \pm 5$ , storage within the temperature range of  $-10^{\circ}\text{C} \pm 5$  to  $55^{\circ}\text{C} \pm 5$ . In case of violation of these temperature conditions, the device can be damaged and battery life can be reduced.
- The recommended humidity for maintaining the device is in the range 50 to 55%.
- Do not expose your device to extreme temperatures or humidity.

Note: Micromax will not bear any responsibility for any non-compliance with the above mentioned guidelines or improper usage of the mobile phone.

## Recycle your Phone



The WEEE logo (shown at the left) appears on the product (handset, and charger) to indicate that this product must not be disposed of or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating

over to the specified collection point for recycling of such hazardous waste.

Collection and proper recovery of your electronic waste equipment at the time of disposal will allow us to help preserve the environment. Recycling of the electronic waste equipment will ensure safety of human health and environment. For more information on best practices for disposal of electronic and electrical waste, please visit to our web site:

[www.micromaxinfo.com/weee.php](http://www.micromaxinfo.com/weee.php).

**Note:** Micromax will not bear any responsibility for any incompliance with the above mentioned guidelines or improper usage of the mobile phone.

## Disclaimers

- The colors, specifications, functions and graphics shown/mentioned in the quick start guide may differ from the actual product. In such a case, the latter shall govern. Images shown are for representation purpose only. Specifications are subject to change without prior notice. Micromax keeps the right to modify the content in this quick start guide without prior notice.
- Talk and standby times are affected by network preferences, type of SIM cards, connected accessories and individual usage patterns. Services and some features may be dependent on the network, service/content providers, SIM cards, compatibility of the devices used and the content formats supported.

- Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.
- Available storage memory may vary based on the phone software.

## Copyright

All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Micromax is strictly prohibited.