



Hardware Specification

- Standard: IEEE 820.15.4
- Operating frequency: 2.405 GHz ~ 2.475 GHz
- Input: Battery 2 x AA
- Dimensions: 4.45" x 2.76" x 1.02" (113mm x 70mm x 26mm)
- Internal PIFA antenna
- Pair/Reset button
- 6 sensor ports
- Status LED

Features

- Fast connection and installation
- Sensors data monitoring from any place
- Notification alerts and status reports

Operating Environment

- Operating temperature: 0°C to 40°C
- Storage temperature: -20°C to 70°C
- Humidity: 20% to 95% non-condensing

TEL : +886-2-2914-5665

FAX : +866-2-2918-6731


E-mail : sales@atomato.com

Specifications in this datasheet are subject to change without prior notice.
Copyright © Atomato Co., Ltd. All rights reserved.




Installation guide


1. Open cover **1**, insert batteries and close the cover.



2. Stick device to any surface using double-sided tape **2** on the back side of device.





3. Plug sensors to any device connector **3** (lower connector on the right side is not used).






4. Sign in to your personal account on the website account.atomato.com.

5. Press shortly button **4** to pair device with Smart Home Controller RF4.0. LED starts blinking green and red. To reset the device press and hold button for 3 sec.



6. Confirm device pairing. After pairing LED blinks green.



On the website an information from sensors can be checked at any time.

Setting up triggers allows to receive immediate notifications via email. Also available receiving the statistical data reports from sensors and saving them to personal account or downloading in PDF format.



FCC Caution

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

Non-modification Statement

Unauthorized antennas, modifications, or attachments could violate FCC regulations. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.