

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generally will not cause radio frequency interference, but it may cause interference to nearby radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the equipment dealer or a qualified radio technician for help.

www.vgtech.com
vgtech@gmail.com
If you have any questions, please feel free to contact us.

MADE IN CHINA

INSTRUCTION MANUAL



WIRELESS MICROPHONE

1 TECHNICAL PARAMETERS

1.1 Comprehensive characteristics

Carrier frequency	862.5MHz (ISM-Band)
Modulation mode	FM
Audio frequency	50Hz-15KHz
Power	10W
Transmitting range	100-200m (line of sight)


1.2 Receiver

Decoding mode	PLL (Digital Frequency Synthesis)
Stop select	ABSD
Stop mode	ABSD
Search mode	ABSD
Audio output interface	14T Output Jack
Working voltage	DC 12V
Working current	1.5A/100mA

1.3 Handheld Transmitter

RF Power output	1.5W/10W
Decoding mode	PLL (Digital Frequency Synthesis)
Frequency stability	±0.001%
Frequency range	862.5MHz
Frequency reference	862.5MHz
Max. test current	1.7A/100mA
Microphone mode	Shooting
Power supply	2x1.5V Dry Cell

2 RECEIVER FRONT PANEL FEATURES AND INSTRUCTIONS




① POWER Button: Press the power switch for 3 seconds, open power supply. LCD is bright, press the power switch for 3 seconds, the receiver power shut down.

② LCD Display: Display system in the current working state.

③ Microphone A VOLUME control: Adjust the audio volume. Counter-clockwise, the volume decreases. Clockwise, the volume increases.

④ Microphone B VOLUME control: Adjust the audio volume. Counter-clockwise, the volume decreases. Clockwise, the volume increases.

3 RECEIVER BACK PANEL FEATURES AND INSTRUCTIONS




① Antenna B connector

② Antenna A connector

③ Microphone A connector

④ Microphone B connector

4 TRANSMITTER FUNCTION AND DESCRIPTION



① Microphone Head: Headset

② Microphone Head: Headset

③ Display Screen

④ Frequency Adjust: Press for 3 seconds, adjust the frequency.

5 SYSTEM SETTINGS

1. Adjust the volume to the standard value based on the transmitter. When not in the receiver, the LCD will display the standard value. When in the receiver, the LCD will display the standard value.

2. When the transmitter is powered on, the battery status will light on. Then adjust the volume. When the volume is adjusted, the LCD will display the standard value.

3. When the transmitter is powered on, the battery status will light on. Then adjust the volume. When the volume is adjusted, the LCD will display the standard value.


4. When the transmitter is powered on, the battery status will light on. Then adjust the volume. When the volume is adjusted, the LCD will display the standard value.

5. The transmitter will automatically adjust the frequency when the receiver is in the receiver. When the transmitter is powered on, the LCD will display the standard value.

6. The transmitter will automatically adjust the frequency when the receiver is in the receiver. When the transmitter is powered on, the LCD will display the standard value.

6 RECEIVER SETTINGS

▼ The display shows under normal working conditions. As shown below:



Receiver LCD display:

- ① RF signal strength: 100%
- ② RF signal strength: 100%
- ③ CHANNEL: display the current working channel
- ④ FREQUENCY: display the current working frequency


7 TRANSMITTER SETTINGS

Handheld transmitter display:

- ① RF signal strength: 100%
- ② RF signal strength: 100%
- ③ CHANNEL: display the current working channel
- ④ FREQUENCY: display the current working frequency
- ⑤ CHANNEL: display the current working channel

8 CONNECTION DIAGRAM


▼ Choose one of the following four connection methods:



Speaker

Note: The best effect work with TV. Usually, the best effect work with TV.

9 ACCESSORIES



10 TROUBLE SHOOTING

Problem	Indicator status	Solution
Receiver LCD display is off	Receiver LCD display is off	Check the battery status. When the battery is low, the LCD display will be off. When the battery is full, the LCD display will be on.
The receiver does not work	Receiver LCD display is off	Check the battery status. When the battery is low, the LCD display will be off. When the battery is full, the LCD display will be on.
The receiver does not work	Receiver LCD display is off	Check the battery status. When the battery is low, the LCD display will be off. When the battery is full, the LCD display will be on.
The receiver does not work	Receiver LCD display is off	Check the battery status. When the battery is low, the LCD display will be off. When the battery is full, the LCD display will be on.