


# Product Introduction




## Quick Setup

**NOTE:** This product support Tuya platform or EWELINK platform. Please download **“Smart Life”** (TUYA platform) or **“eWeLink”** (EWELINK platform) in APP store / Google play, also can scan the below QR code to install official APP



Smart Life




eWeLink

**Notice:** Make sure the Zigbee gateway has been in your device listing in Smart life APP

Remove the insulation sheet and press the pairing button for 5seconds, the LED will blink, then enter into gateway homepage and click **“Search new device”** or **“Add Devices”** and follow the in-app instructions to connect the device to your gateway.

## ● Device Installation

Install the device at the place where you want with double side tape. The alignment marks must be close together as possible (Must be≤15mm)



## ● Battery Replacement

The device powered by 2 CR1632 batteries. If you want to replace the battery, just slide the upper cover to open it and replace the battery (the negative pole to the PCB)

**APPENDIX:**  
**How do connect device in Home Assistant**

Note: Before setup device, you need make sure the Home Assistant system has been installed on host device (computer or Raspberry Pi) and the Zigbee Coordinator (USB dongle) has been added in Home Assistant system.

There are two ways to connect device with home assistant.

a) ZHA(Zigbee Home Automation)

①. Log in [“http://x.x.x.x:8123”](http://x.x.x.x:8123) (x.x.x.x is the IP address of home assistant) via web browser or home assistant APP;

②. click **“Settings -> Devices & Services -> ZHA(Zigbee Home Automation) -> Add Devices”**, press the button of device for 5 seconds then the LED blinks, the device will connect to home assistant in a moment

**+ ADD DEVICE**

**Note:** If there is no ZHA on your home assistant, you have to add it first via **“ADD INTEGRATION”**

**ADD INTEGRATION**

**2-2. Zigbee2MQTT**

①. Log in [“http://x.x.x.x:8123”](http://x.x.x.x:8123) (x.x.x.x is the IP address of the home assistant) via web browser or home assistant APP;

②. Click **“Settings -> Add-ons -> Zigbee2MQTT -> OPEN WEB UI -> Permit join(All)”**, press the button of device for 5 seconds then the LED blinks, the device will connect to home assistant in a moment

**Permit join (All)**

**Note1:** If there is no the Zigbee2MQTT on your home assistant, you have to add it first via **“ADD-ON STORE”**;

**ADD-ON STORE**

**Note2:** If the device is not supported by Zigbee2MQTT, you need update the Zigbee2MQTT to the latest version.

**● FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.