

Quick Start Guide

Congratulations on your purchase of the floorsight desk booking puck sensor. The following instructions will walk you through the process of turning on your puck and mapping it to a location on a floorsense controller floorplan.


Prerequisites

In order to operate the floorsense sensor and discover occupancy data you will need to deploy the floorsense controller hardware and have an account setup at floorsense.com.au. The floorsense controller should be deployed prior to attempting to activate the desk booking puck. For more information on floorsense controllers please visit <https://support.smartalock.com/support/solutions/articles/5000847692-floorsense-administrator-guide>

Configuration

Turning on your floorsight desk booking puck

1. Unpack your floorsight puck and identify the installation location
2. Connect the 24V DC power supply to the power in jack
3. The LED light on top of the puck will flash red and then green. After between 30-60 seconds the LED will go solid green once it connects to the floorsense controller. This connection uses the pucks built in 915mhz radio which is preconfigured for your site and not user configurable.
4. Install the floorsight puck in its final location - for example in a void cut into a desk. See the hardware installation guide at <http://support.smartalock.com/support/solutions/articles/5000803912-floorsight-and-floorsense-installation-instructions>



To operate the wireless charger place wireless charging client device (ie smartphone) onto the top of the puck where the lightning bolt indicator is at the centre of the charging coil. Different phones have different charging hotspots. You may need to move the phones around slowly to find the best charging location on the top of the puck.

To operate the NFC Reader: swipe compatible ISO14443A access card onto the area on the puck marked with the swipe card symbol

Bluetooth operation: The puck emits a bluetooth beacon which is compatible with the floorsense iOS and Android smartphone apps. The Bluetooth beacon contains the pucks serial number which is used by the floorsense iOS and Android app to identify the desk number the puck is installed at. There is no other use for Bluetooth connectivity. 2-way Bluetooth connection to the puck is not possible.

There is a microUSB port on the side of the puck. This is for technician use only to perform a factory upgrade of the puck firmware. It is not for end user use.

Thats it! Navigate to the floorsense controller web portal to map the floorsight desk booking puck to a floorplan location. If The LED does not transition to solid green check support.smartalock.com for more information.

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. – Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and all persons. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.