



# **MWC-936 User Manual**

**5G NR-U Wireless Bridge**

**Rev. 1.0**

**2023-08-08**

**■ Revision History**

Date	Written by	Rev.	Description
23.08.08	Sun.Lee	1.0	MWC-936 User manual v1.0

Address: Room 504, 106-40 Gwahakdnji-ro, Gangneung-si, Gangwon-do.  
25440 KOREA.

<http://www.miliwave.co.kr/>  
Tel. 070-8825-0630  
Fax.  
Email: sales@miliwave.co.kr

**Copyright** © Miliwave Inc. 2020. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Miliwave Co., Ltd. All specification supplied herein are subject to change without notice at any time.

## **1. Introduction**

### **1.1 Overview**

The MWC-936 5G NR-U Wireless Bridge uses the 60GHz radio frequency band to form a wireless bridge with a transmission rate of 2Gbps in both directions.

It supports IEEE 802.11ad Standard and can use Ch1~Ch4.

It has an 1Giga Ethernet LAN port interface. (Circular M12 connector).

And there is an RJ45 port for power supply. This port support Passive PoE(Typ 48V), and data communication will be applied in a later update version.



< Figure 1. MWC-936 >

For more information, please contact your Miliwave ([sales@miliwave.co.kr](mailto:sales@miliwave.co.kr))

## 1.2 Abbreviations and Acronym Definitions

Acronym	Definition
Gbps	Giga bits per second
GHz	Giga Hertz
IEEE	Institute of Electrical and Electronics Engineers
LED	Light Emitting Diode
LoS	line-of-sight
Mbps	Mega bits per second
MCS	Modulation and Coding Scheme
MHz	Mega Hertz
PTMP	Point-to-multipoint Communication
QAM	Quadrature amplitude modulation

## 2.0 Technical Specifications

Parameter	Description
SOC	Dual core ARMv8 Cortex-A53
PoE	Passive PoE (Typ 48V)
Operating Frequency	802.11 ad : CH1, CH2, CH3, CH4 58.32GHz ~ 64.80GHz
Transmit Power(max.)	30 dBm @ MCS1 (ANT Beamforming Index 21)
Input Voltage	Voltage: 48V(typ), Current: 500mA
Power Consumption	Data Transfer mode: Typical 18W ( at Max. Power )
Operating Temperature	-40°C ~ +85°C
Storage Temperature	10°C ~ + 40°C
Operating Humidity	5%~95%
Storage Humidity	5%~95%
Volume (L x W x H)	105 x 120 x 50 mm
색상	Black
Weight	Typical 0.6 kg
Input / Output Port	Circular M12 Female connector (1Gbps) x1 RJ45 port x1 (This port is used for power. Data communication will be operated in the next version)

### 3.0 Web UI user guide


#### 3.1 Login

1. Open your web browser, then go to <https://192.168.1.1>.
2. Enter the device login username and password.


The default username and password are as follows:

**Username:** admin


**Password:** admin




1. Your device's home page (or dashboard) should be displayed.




#### 3.2 Device Overall Status



#### 3.3 Wireless Status




### 3.4 Password Change



### 3.5 IP Network Settings



### 3.6 Wireless Setting



## 4.0 Installation

It is installed with power supply through Passive PoE (Typ 48V).

## 5.0 FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

The device must be installed such that a minimum separation distance of at least 25.15 cm is maintained between the radiator (antenna) and all persons at all times.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.