

Model: MS62143




PHONIC 10

PORTABLE BLUETOOTH SPEAKER

Quick Start Guide

Please read this Quick Start Guide carefully and keep it for future use

Product Overview



- 1. Indicator Light**
- 2.Multifunction Knob**
- 3.Recording Function**
Short press: Enter recording mode
Long press: Delete the currently playing recording file
- 4.Previous song**
Short press: Previous song
- 5.Play/Pause**
Short press: Play/pause
- 6.Next song**
Short press: Next song
- 7.Mode switch**
Short press: Mode switching

- 8.MIC Input Port**
Used to connect a wired microphone for voice input
- 9.USB (Audio) Input**
Connect a USB storage device
- 10.USB-C Charging**
Connect a Micro SD card mode storage device
- 11. Micro SD card Input**
Connect a Micro SD card mode storage device
- 12.Charging Indicator**

LED Indicator/Prompt tone Guide

	Describe	Prompt tone	Status
Indicator Light	The white light flashing	Power on tone	Power on
	All lights off	Power off tone	Power off
Indicator Light	The white light flashing	-	Not connected
	The white light stays on	Connected tone	Connected
Low battery	The red light flashing	Low battery tone	-
Speaker charging	Charging in progress, the red charging indicator light stays on	-	-
	After fully charged, the red charging indicator light off	-	-

Power/Charging

For better enjoyment, fully charge the speaker before use.
A USB-C charging cable (charge only) is included for standard USB compatible device.
Please use a 5V/1A or above power adapter (not included).
Caution: - Other incompatible charges may cause damages.
- Do not use if the connector or device is wet or damaged.

Power On/Off

To turn on the speaker, rotate the multifunction knob clockwise to power it on. A startup tone will be heard.
To turn off the speaker, rotate the knob counterclockwise. A shutdown tone will be heard.
Caution: If no Bluetooth device is connected, the speaker will turn off in 15 minutes.

Bluetooth Connection

- When first used and turned on, the speaker will automatically enter a waiting mode for connection.
 - The speaker will automatically enter pairing mode if it is not connected to a Bluetooth device.
- When connecting, enable the Bluetooth function of the mobile phone, search for "**Monster Phonic 10**" and connect. After the connection is successful, you will hear a prompt tone, the white light of stays on.

Music Control

Short press "▶|◀" music can be played or paused.
Short press "◀◀" to go to the previous song.
Short press "▶▶" to go to the next song.

Volume Control

Turn counterclockwise to decrease volume.
Turn clockwise to increase volume.

USB IN (Audio) Playback

When speaker is on and USB drive is inserted, USB IN (Audio) is the priority playback source. If you want to use Bluetooth function, press the "M" button to switch the source.

Micro SD Card Playback

When speaker is on and micro SD card (not included) is inserted, micro SD card is the priority playback source. If you want to use Bluetooth function, press the "M" button to switch the source.

Recording

When a micro SD card or USB flash drive is inserted, short press the "⏻" button to start recording. Press the "⏻" button again to stop recording and automatically play back the current recording. Newly recorded files are given the highest playback priority, followed by previously saved recordings. During playback, short pressing any button will exit recording playback mode.

Recording Playback

In micro SD card or USB playback mode, short press the "◀◀" button to play the previous recording, short press the "▶▶" button again to play the next recording.

Delete Recording

While in recording playback mode, long press the "⏻" button for 2 seconds to delete the current recording file.

Power Saving Settings

- In Bluetooth mode, when no device is connected, the speaker will be switched off automatically in 15 minutes.
- AUX IN mode/ Micro SD card mode no music playback for 15 minutes, the speaker will be switched off automatically.

Reset Device

If the speaker needs to be reset, press and hold the "▶|◀" button for 8 seconds.

Caution

- It is not recommended to replace the battery privately.
- The battery (battery pack or battery pack combination) must not be exposed to sunshine, fire or similar overheated environments.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

For service, warranty, or product information,
Please contact: support@mict-audio.com with your order ID.

FCC ID: 2AVD2-MS62143

IC Caution

Radio Standards Specification RSS-Gen, issue 5
- English:
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- French:
Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:
Cet appareil ne doit pas causer d'interférences.
Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF:
L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.
IC: 28087-MS62143