

User Manual

Normal working mode:

- 1) Connect the card reader to the USB interface of the computer / laptop, the device is powered
- 2) The device starts working, red LED is bright
- 3) The computer will automatically identify the USB driver of the device within 30 seconds
- 4) Open TXT documentation
- 5) Place the label above the card reader, the device reads the tag UID, the UID will be displayed at the computer cursor. When the device reads the label, the buzzer will sound while LED turning blue light.

Specification

- Type: Contactless R/O or R/W Reader
- Operating Frequency: HF (13.56MHz)
- IC Available at 13.56MHz:
I-CODE (ISO 15693-3), Mifare® Ultralight (ISO 14443A), Mifare®1K (ISO14443A)
- Reading Range: up to 5~20cm
- Power Supply: DC+5V
- Working Current: 35mA
- Working Temperature: -30° C to +70° C
- Interfaces: USB or RS232

Competitive Advantage

1. Long Reading Distance
2. High anti-collision performance
3. Settable for transmission time

Remark:

1. *Specifications are subject to change, please pay attention to our latest one.*
2. *DAILY RFID reserve the right to the final interpretation of the above terms.*

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction