

AC1200 Dual Band GPON Terminal

封面

- NP1269GB x 1
- Power Adapter x 1
- Fiber Cable x 1
- Quick Installation Guide x 1

Diagram of the rear panel of the HP ProCurve 2530-27 PoE switch. The top section shows the Wi-Fi Button, USB Host, WPS Button, WPS/Wi-Fi indicator, Reset Button, and USB port. The bottom section shows the Power Port, FXS Ports, ON/OFF Button, GE Ports, and PON Port.

Diagram illustrating the connection steps:

1. Connect the Fiber cable to the TEL2 port.
2. Connect the Laptop to the LAN1 port.
3. Connect the TEL (Optional) to the TEL1 port.
4. Connect the Power adaptor to the POWER port.

- ① Connect a fiber cable to the PON port.
- ② Connect a computer to the GE port using the Ethernet cable.
- ③ Connect a telephone to the TEL port using the PHONE cable.
- ④ Use the included power adapter to connect the power socket to a power outlet. Press the **ON/OFF** button to turn on the device.

- **Using SSID**
Use the **SSID** and **Wireless Key** on the device label to connect wireless to the device. On your smartphone or notebook, find this **SSID**. Enter the Wireless Key to connect.
- **Using WPS**
Press the **WPS** button on the device and the **WPS** indicator will blink. Then press the **WPS** button on the client. If the WPS method fails, use the SSID and wireless key to set up a WiFi connection.

Launch a web browser and go to **Default IP** showing on the label, then enter the default **User Name** and **Login Password** to Log in. You can configure it on the web page.

Name	Explanation
ON/Off	Turn on/off the device.
RESET	Hold down for more than 5 seconds and release to restore the factory settings.
WPS	Press the button to connect the device through WPS.
WIFI	Enable/Disable wireless network

Name	State	Description
Power	On	The device is powered on.
	Off	Power is off.
Internet	On	In Routing mode and the WAN connection is connected.
	Off	No internet connection or the modem router is operating in Bridge mode.
PON/ LOS	On	The device has been registered successfully.
	Blinking green	Optical signal is detected.
	Blinking red	Without optical signal or abnormality.
WIFI	On	Wi-Fi has been turned on.
	Blinking	Wi-Fi data are being transmitted by WLAN band.
	Off	Wi-Fi is closed.
LAN	On	The LAN port is properly connected.
	Blinking	Data are being transmitted through LAN port.
	Off	The LAN port is not connected.

TEL	On	The VOIP server has been registered.
	Blinking	The voice service is in use.
	Off	The VOIP server is not registered.
WPS	On	The device is successfully connected through WPS function.
	Blinking	The device is being connected through WPS function.
	Off	The WPS function is not enabled, or 5 minutes after the device is successfully connected through WPS function.

Operating Temperature	0°C~40°C
Storage Temperature	-40°C~70°C
Relative Humidity	10%~90% non-condensing
Storage Humidity	5%~95% non-condensing

How to Wall-mount

Mark the two bracket holes using a pencil (not included).

106.5mm

MARK HERE

MARK HERE

Fasten the screws to the wall on the bracket holes.

Hang the device on the screws.

Screw Size: M4 x 20mm

This type of mounting is not recommended

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20cm from all persons.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.