

ORVIBO

MixPad D1

User Manual

Shenzhen ORVIBO Technology Co., Ltd.
7F, Building A7, Nanshan Hi-Tech Incubator, No.1001
Xixun Avenue, Nanshan District, Shenzhen, China
518055, PRC
support.us@orvibo.com www.orvibo.com

Any help needed, please contact us by
support.us@orvibo.com
Support: <https://www.orvibo.com/en/support>

Thank you for choosing MixPad D1

MixPad D1 switch is a standard size smart dimmer switch that can quickly turn a traditional switch into a smart one.
It combines four types of interaction: buttons, touch screen, voice and mobile app, while using Wi-Fi communication protocols. You can quickly control the lights through the button, precisely control through the touchscreen, remotely control through mobile app, voice control through Alexa or Google Assistant.
It is a collection of device control, voice intercom, weather display and other applications of the wall smart switch.

Specification

Microphone

Loudspeaker

Touch Screen

Short Press: Light ON/OFF

Long Press: Voice ON/OFF

Fast Switching Tab

You can pull out the Fast Switching Tab to cut power off

01

02

MixPad D1

Model: V70X-M
Power supply: 120V/60Hz
Input Voltage: 150~250VAC 50/60Hz
Load Range: Max 250W INC./HAL
Max 120W LED/CFL
Max 250W MLV/ELV

Load: Load
L: Line
N: Neutral
G: Ground

Package List

Front Panel x1

MixPad D1 Switch x1

Plate Screws x2

Mounting Screws x2

User Manual x1

Wire Nuts x4

Wire Labels x1

03

04

Product Specification

Model	V70X-M
Product Size	4.12"×7.91"×0.80"
Input Voltage	150~250VAC 50/60Hz
Load Range	Max 250W INC./HAL Max 120W LED/CFL Max 250W MLV/ELV
Communication Mode	2.4GHz Wi-Fi, Bluetooth 4.2 (not compatible with 5GHz Wi-Fi)
Operating Environment	Temperature 32~113°F, humidity <50%/rh
Storage Environment	Temperature -4~158°F, humidity <90%/rh

Check Compatibility Before Installation

Is the power supply in your house 120V/60Hz?

MixPad D1 switch supports 120V/60Hz power (standard for US and CA houses).

Is there a neutral wire in the junction box?

MixPad D1 switch requires a neutral wire for installation.

What is the power of your lamp?

Lamp Type	Load Range
INC./HAL	250W Max
LED/CFL	120W Max
MLV/ELV	250W Max

Is the replacement switch controlling the fan or calling fan with light?

The MixPad D1 switch only supports light switch, not fan or ceiling fan with light.

05

06

Preparation Tools

Flat-head Screwdriver

Phillips-head Screwdriver

Pliers

Power tools are not recommended.

!

Installing this product involves handling high voltage wiring. Each step of the enclosed instructions must be followed carefully. To avoid fire, personal injury, or death, turn off your circuit breakers and follow the proper safety procedures before proceeding.

UNSURE ABOUT HANDLING ELECTRICAL WIRING?
CONSULT A QUALIFIED ELECTRICIAN.

The product should be used indoors only and should not be installed in wet environments such as bathrooms. Do not attempt to repair the product by yourself, it should be repaired by an authorized professional.

07

08

Single Pole Installation

1 Turn off the power

Turn off the circuit breaker, then turn the light on and off several times to verify that the power is off.

2 Remove Panel

Remove the wall switch screws and gently pull the switch out, but do not disconnect the wires.

3 Take a Photo

Take a picture showing the existing wire connections from the wall to the back of the switch. This will be useful if you need to reconnect your previous switch.

4 Identify the Neutral and Ground wires

In the junction box, the white wire fixed with the wire nut is Neutral wire.

09

10

封底

封面

5 Turn on the power

In the junction box, the green or bare copper wire is Ground wire.

6 Identify the Line/Load wires

Identify the wire with the electrical tester. The Line wire is energized when the light is turned on or off, and the load wire is only energized when the light is turned on (usually Line and Load wires are Black and Red respectively).

Identify the wires need to operate with electricity, do not touch the bare metal with your body.

11

12

7 Turn off the power

8 Marking wires with wire labels

9 Remove the switch

Remove the switch after labelling the wires.

13

14

10 Connect the wires

Make sure the circuit breaker is power off. Use wire connectors to connect the wires on the MixPad D1 to the labeled wires coming from the wall in order.
1 Connect Neutral wires
2 Connect Ground wires
3 Connect Line wires
4 Connect Load wires

11 Install the switch

With light pressure, push your MixPad D1 into the switch box. The switch should sit flush against the wall—if not, pull the switch out and try rearranging the wires.

Please do NOT force the switch into the wall.

15

16

12 Install the panel

Secure the mount with screw and then fix the front panel to complete the installation.

Configure MixPad D1

*As software evolves, the latest user interfaces may differ slightly from what is described in this manual. Follow the 3 steps to complete the device configuration for MixPad D1.
Step 1: Download the App
Path ①: Search "ORVIBO Home" In the App Store or Google Play Store to download the App.
Path ②: Scan the QR code with your mobile phone to download the App.
ORVIBO HOME
After download the App, register a new account and log in.

17

18

Step 2: Turn on the circuit breaker to start the device.

2 Select the type of light
• Dimmable: For Dimmable type, the Minimum and Preference brightness could be set by sliding up or down.
• Non-dimmable

Step 3: Follow the on-screen instructions to complete the configuration.

1 Click Start to set up
2 Select the type of light
3 Select the type of light
4 Select the type of light

19

20

3 Open the ORVIBO Home App, scan the QR code on the screen to complete the device network connection and account binding according to the instructions. Click the "i" on the right corner of the app's home page and scan the QR code to complete the network connection.

4 Complete Configuration

Basic Operations
Physical Button
Short Press: Turn the light on/off
Long Press (5s): Turn microphone off/on

21

22

Swipe Left or Right

Swipe left or right to switch control and settings pages for different devices.

Common Functions

Control Lights
The light can be turned on/off and the percentage of brightness can be adjusted through touch screen, voice and App, and the physical button can only turn on/off the light.
* With ORVIBO smart switches, controlling other lights on one MixPad D1 can be achieved. More instructions are on page 27.
* Voice control requires Amazon Alexa or Google Assistant

23

24

Mode Control

1 Vacation Mode: Lights turn on/off randomly when you are away to keep your home safe.
2 Automatic Mode: The light turns on automatically when the device detects that the room is dark, and turns off automatically when the room is bright.
3 Customised Mode: The light brightness can be edited to suit your needs, e.g. 50% brightness for reading mode. There are two ways to customize:
• On App: Go to "Me"-"Device Management"-"All Devices", select the device and go to "Setting"-"Mode Manager"-"Add Mode" to set the name of the icon, then MixPad D1 switch will sync the information to match the settings.
• On MixPad D1: Click "Add" to set different brightness, a total of 4 icons can be added to indicate the customized mode.

25

26

Control Other Devices

Intercom function enables voice intercom with other rooms.
Scene Control
Define different scenes based on your needs, so that you can control multiple devices with one click, e.g. turn off all the lights when you leave home.
Go to "Smart"-"Scenes" and click "+" in the right corner to set the scene. After finishing the setting in the app, the scene information will be displayed on the screen of MixPad D1.

27

28

Voice Intercom

Intercom function enables voice intercom with other rooms.
* Voice intercom function requires two MixPad D1 switches to be in the same WLAN.

Voice Broadcast

Broadcast function enables MixPad D1 switches in all rooms to broadcast voice simultaneously.
Press and hold the button to turn on the broadcast, and release to stop the broadcast.
* Voice broadcast function requires all MixPad D1 switches to be in the same WLAN.

29

30

Voice Control via Siri

Do not have an Alexa or Google Home device? If you have an Apple mobile device, you can enable Siri voice control to the scenes you created.
Log in to the ORVIBO Home App, go to "Me", find "Siri Shortcuts", and click "Add" to Siri to customize voice control from Apple devices to home appliances.

Support Amazon Alexa and Google Home

1. Link ORVIBO to Amazon Alexa/Google Assistant
Log in to the ORVIBO Home App, go to "Me", find "Smart speaker service", and click "Amazon Alexa" or "Google Home" for detailed instructions.
2. Control by Amazon Alexa/Google Assistant
Voice command reference:
Amazon Alexa: Alexa, turn on the lights
Alexa, turn off the lights
Google Assistant: Hey Google, turn on the lights
Hey Google, turn off the lights

31

32

Set up with Matter

You can integrate this device into any Matter ecosystem you prefer for controlling by its App or setting up routines with other Matter devices.
How to Set Up:
A Matter-supported controller and smart home app of the same ecosystem are required.
1. Turn on Bluetooth on your phone.
2. Open the smart home app and scan the access QR code provided in the initial settings or "Setting" - Add to App - "Matters App" on the screen of MixPad D1.
3. Follow the instructions in the app to complete setup.
Note: Setup processes may vary between different ecosystems.
Failed to Set Up?
1. Try to connect your phone to a stable 2.4GHz Wi-Fi network with internet access instead of a 5GHz network;
2. Turn off, then turn on the power to restart the device;
3. Refer to the FAQ for detailed instructions.
<https://www.orvibo.com/en/support/supportfaq.html>

Warranty Range And Duration

One year warranty applies to most ORVIBO products unless specified at the time of purchase. Accessories included with the main device and batteries have a warranty of six months when buying ORVIBO products, the product warranty remains measured from the time it was bought by the original owner. Any other promises made by dealers beyond the guarantee of ORVIBO, ORVIBO will not assume any liability.
The following cases do not belong to free repair scope and ORVIBO will provide paid services. Please note: Fill to provide warranty card and related sales invoices. Cleaning of product and wear loss under normal circumstances such as natural loss of casing, mounting components, aging and wear.
Any product failure or damage caused by installation, usage maintenance, and storage that are not in accordance with usage instructions. After or tear up barcode on products or warranty card without authorization.
For those beyond change or warranty period.
Product serial number or type on warranty card does not match the product itself. Without getting the permission of ORVIBO, change its inherent structure circuit privately, or dismantling or modifying without authorization.
Product damage caused by accident, human abuse/ misuse, such as output short circuit, high-voltage

33

34

Input, overload work, high temperature, water inflow, mechanical damage, broken serious oxidation or rusty and etc.
Damage caused by transportation loading and unloading on the way of return for repair.
Product failure or damage caused by force majeure such as earthquake, fire, flood lightning and so on.
Product failure or damaged caused by any problem other than product design, technology, manufacturing, quality and others. Accessories are not included in free repair scope. This regulation shall come into effect since the issuing date.
ORVIBO will keep the final interpretation right and revise.

FCC
FCC Statement
This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the Notice. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the Instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
RF Exposure Information
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.
FCC ID: 2AWF7-V70X-M

35

36